



# **648-Port InfiniBand QDR SwitchX® Switch Platform Hardware User Manual**

PN:MIS5600Q-10DNC

Rev 2.7

[www.mellanox.com](http://www.mellanox.com)

NOTE:

THIS HARDWARE, SOFTWARE OR TEST SUITE PRODUCT ("PRODUCT(S)") AND ITS RELATED DOCUMENTATION ARE PROVIDED BY MELLANOX TECHNOLOGIES "AS-IS" WITH ALL FAULTS OF ANY KIND AND SOLELY FOR THE PURPOSE OF AIDING THE CUSTOMER IN TESTING APPLICATIONS THAT USE THE PRODUCTS IN DESIGNATED SOLUTIONS. THE CUSTOMER'S MANUFACTURING TEST ENVIRONMENT HAS NOT MET THE STANDARDS SET BY MELLANOX TECHNOLOGIES TO FULLY QUALIFY THE PRODUCT(S) AND/OR THE SYSTEM USING IT. THEREFORE, MELLANOX TECHNOLOGIES CANNOT AND DOES NOT GUARANTEE OR WARRANT THAT THE PRODUCTS WILL OPERATE WITH THE HIGHEST QUALITY. ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NONINFRINGEMENT ARE DISCLAIMED. IN NO EVENT SHALL MELLANOX BE LIABLE TO CUSTOMER OR ANY THIRD PARTIES FOR ANY DIRECT, INDIRECT, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES OF ANY KIND (INCLUDING, BUT NOT LIMITED TO, PAYMENT FOR PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY FROM THE USE OF THE PRODUCT(S) AND RELATED DOCUMENTATION EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.



Mellanox Technologies  
350 Oakmead Parkway Suite 100  
Sunnyvale, CA 94085  
U.S.A.  
[www.mellanox.com](http://www.mellanox.com)  
Tel: (408) 970-3400  
Fax: (408) 970-3403

Mellanox Technologies, Ltd.  
Beit Mellanox  
PO Box 586 Yokneam 20692  
Israel  
[www.mellanox.com](http://www.mellanox.com)  
Tel: +972 (0)74 723 7200  
Fax: +972 (0)4 959 3245

© Copyright 2014. Mellanox Technologies. All Rights Reserved.

Mellanox®, Mellanox logo, BridgeX®, ConnectX®, Connect-IB®, CORE-Direct®, InfiniBridge®, InfiniHost®, InfiniScale®, MetroX®, MLNX-OS®, PhyX®, ScalableHPC®, SwitchX®, UFM®, Virtual Protocol Interconnect® and Voltaire® are registered trademarks of Mellanox Technologies, Ltd.

ExtendX™, FabricIT™, Mellanox Open Ethernet™, Mellanox Virtual Modular Switch™, MetroDX™, Unbreakable-Link™ are trademarks of Mellanox Technologies, Ltd.

All other trademarks are property of their respective owners.

# Table of Contents

<b>List of Tables</b> .....	<b>5</b>
<b>List of Figures</b> .....	<b>6</b>
<b>Revision History</b> .....	<b>8</b>
<b>About this Manual</b> .....	<b>9</b>
<b>Chapter 1 Overview</b> .....	<b>11</b>
1.1 Product Information .....	11
1.1.1 Serial Number and Product Version Information .....	11
1.1.2 License Key .....	12
1.1.3 Management Module MAC .....	12
1.1.4 Product Physical Specifications and Power .....	12
1.2 Features List .....	14
1.3 Power Supply Redundancy .....	14
<b>Chapter 2 Installation</b> .....	<b>15</b>
2.1 Installation Safety Warnings .....	15
2.2 Environmental and Safety Recommendations .....	19
2.3 Chassis Package Contents .....	20
2.4 Leaf Package Contents .....	21
2.5 Management Package Contents .....	21
2.6 Physical Installation .....	21
2.6.1 Starting with the Rack .....	22
2.6.2 ESD Connection .....	23
2.6.3 Installation Procedure .....	23
2.6.4 Installing the Cable Holder .....	40
2.6.5 Ground Connections .....	41
2.7 Power Connections .....	41
2.7.1 Powering Up the Switch Platform .....	42
2.8 InfiniBand QSFP Cable Installation .....	43
2.8.1 Supported Approved Cables .....	44
2.8.2 Cable Power Classes .....	44
2.9 Hot Swap Insertion and Extraction .....	44
2.9.1 Power Supply Units .....	45
2.9.2 Leaf Boards .....	46
2.9.3 Spine Boards .....	50
2.9.4 Fan Modules .....	54
2.9.5 Management Module .....	57
2.9.6 Switch Shut-Down Procedures .....	59
<b>Chapter 3 Interfaces</b> .....	<b>61</b>
3.1 LED Status Indicators .....	61
3.1.1 Power Supply Unit LEDs .....	61
3.1.2 Leaf Board LED Indicators .....	62
3.1.3 Spine Board LED Indicators .....	63
3.1.4 Spine Side Panel Display LED Indicators .....	65
3.1.5 Management Module LED Indicators .....	66

3.1.6 Port Connector Interfaces .....	68
3.2 Air Flow .....	68
3.3 QSFP Cable Power Budget Classification .....	68
3.4 Management Module Interfaces .....	69
3.4.1 I2C .....	69
3.4.2 CONSOLE .....	69
3.4.3 MGT– Management .....	69
3.4.4 USB .....	70
3.4.5 Reset – RST .....	70
<b>Chapter 4 Chassis Power Up .....</b>	<b>71</b>
4.1 Power Supply and Spine Board Indicator Status at Power ON .....	72
<b>Chapter 5 Switch Management Tools .....</b>	<b>73</b>
5.1 InfiniBand Subnet Manager .....	74
5.2 Accessing the CPU via the Ethernet Connector .....	74
5.3 Upgrading Software .....	74
<b>Chapter 6 Troubleshooting .....</b>	<b>75</b>
6.1 Power Supply Unit .....	75
6.2 Leaf Board .....	75
6.3 Management Module .....	76
6.4 Spine Board .....	77
6.5 FabricIT Software .....	77
<b>Chapter 7 Disassembly and Disposal .....</b>	<b>78</b>
7.1 Disassembling the Chassis .....	78
7.1.1 Removing the Chassis .....	80
7.1.2 Removing the Bottom Shelf .....	81
7.2 Disposal .....	81
<b>Appendix A Specification Data .....</b>	<b>82</b>
A.1 EMI Certification .....	83
A.2 Approved Cables .....	83
A.3 EMC Certifications .....	84
<b>Appendix B Calculating the Weight of a Customized Chassis .....</b>	<b>85</b>
<b>Appendix C Calculating the Power of a Chassis .....</b>	<b>86</b>
<b>Appendix D Mechanical Drawing .....</b>	<b>87</b>
<b>Appendix E QSFP Interface .....</b>	<b>89</b>
<b>Appendix F Replacement Parts Ordering Numbers .....</b>	<b>91</b>
<b>Appendix G Installation Safety Warnings .....</b>	<b>93</b>
G.1 Installation Safety Warnings (English) .....	93
G.2 安裝安全性警告 (Chinese) .....	97
G.3 Avertissements de sécurité pour l'installation (French) .....	102
G.4 Installation Sicherheitshinweise (German) .....	107
G.5 Advertencias de seguridad de instalación (Spanish) .....	111
G.6 Предупреждения по технике безопасности при установке (Russian) .....	115
G.7 Avertismente privind siguranța la instalare (Romanian) .....	119
G.8 Sigurnosna upozorenja za instaliranje (Croatian) .....	124

## List of Tables

Table 1:	Revision History of this User's Manual. . . . .	8
Table 2:	Reference Documents and Websites. . . . .	10
Table 3:	Leaf Status LED. . . . .	62
Table 4:	Connector Physical and Logical Link Indications. . . . .	63
Table 5:	Spine Status LED. . . . .	64
Table 6:	Spine Fan Status LED. . . . .	64
Table 7:	Spine to Leaf IB Link Status. . . . .	65
Table 8:	LEDs Display for Normal Operation. . . . .	65
Table 9:	LEDs Display for Normal Operation. . . . .	66
Table 10:	Management Module PSU LED Configurations. . . . .	67
Table 11:	Management Module S.Fan LED Configurations. . . . .	67
Table 12:	Management Module L.Fan LED Configurations. . . . .	68
Table 13:	Management Module MASTER LED Configurations. . . . .	68
Table 14:	IS5600 Switch Specification Sheet. . . . .	82
Table 15:	Power Consumption of Chassis Parts. . . . .	86
Table 16:	InfiniBand QSFP Connector Pinout. . . . .	89
Table 17:	Replacement Parts Ordering Numbers. . . . .	91

## List of Figures

Figure 1: Product Label .....	11
Figure 2: License Key Label .....	12
Figure 3: Product Label Tab Location .....	12
Figure 4: Management Module MAC Address Location .....	12
Figure 5: IS5600 Switch Views .....	13
Figure 6: Distance Between the Vertical Supports .....	22
Figure 7: Installation Kit Parts .....	24
Figure 8: Shock and Tilt Stickers .....	25
Figure 9: Container Screws .....	26
Figure 10: Vertical Rack Supports Dimension .....	28
Figure 11: Placement of Chassis in Rack .....	28
Figure 12: Adjustable Shelf Brackets .....	29
Figure 13: Placing the Shelf Bracket .....	29
Figure 14: Caged Nut Locations for the Shelf Brackets .....	30
Figure 15: Shelf Brackets .....	30
Figure 16: U Numbering Above Shelf .....	31
Figure 17: Putting the Chassis in the Rack Using a Fork Lift .....	32
Figure 18: Putting the Chassis in the Rack Using a Mechanical Lift .....	32
Figure 19: Place the Upper Bracket Offset .....	33
Figure 20: Attach the Shelf Extension .....	33
Figure 21: Place Caged Nuts .....	34
Figure 22: Location for the Lock-Down Bar .....	34
Figure 23: Fork Lift .....	34
Figure 24: Mechanical Lift .....	35
Figure 25: Face Plate Mounting Bolt Locations .....	36
Figure 26: Upper Bracket Installation .....	37
Figure 27: Upper Brackets and Offset Location .....	37
Figure 28: Offset to Upper Bracket Bolts .....	37
Figure 29: Location for the Lock-Down Bar .....	38
Figure 30: Lock-Down Bar .....	38
Figure 31: Lock-Down Bars Bolt and Washer Order .....	38
Figure 32: Spine Side with Filler Panels .....	39
Figure 33: Cable Holder .....	40
Figure 34: Ground Connection .....	41
Figure 35: Multiple Power Inlets – Electric Caution Notification .....	42
Figure 36: Spine Module .....	43
Figure 37: Power Cord Numbering .....	45

Figure 38: PSU and Outlet Locations .....	45
Figure 39: Power Supply .....	46
Figure 40: Ejector Handle .....	47
Figure 41: Leaf Release .....	48
Figure 42: Intact vs Defected Signal Connectors .....	48
Figure 43: Intact vs Defected Power Pin Holders .....	49
Figure 44: Management Module Numbering .....	51
Figure 45: Spine Board Extraction .....	51
Figure 46: Intact vs Defected Mechanics .....	52
Figure 47: Intact vs Defected Side Signal Connectors .....	53
Figure 48: Intact vs Defected Middle Signal Connectors .....	53
Figure 49: Intact vs Defected Power Pin Holders .....	53
Figure 50: Leaf Fan Locations on the Chassis .....	55
Figure 51: Leaf Fan Module Extraction .....	55
Figure 52: Spine Fan Module .....	56
Figure 53: Fan Status LED on the Spine Module .....	56
Figure 54: Management Module .....	58
Figure 55: Intact vs Defected Signal Connectors .....	58
Figure 56: Intact vs Defected Power Pin Holders .....	59
Figure 57: Power Supply Unit Status Indications .....	61
Figure 58: PSU Cover On and Off .....	62
Figure 59: Leaf Board Led Indicators .....	62
Figure 60: Spine Status LEDs .....	64
Figure 61: Spine Side Panel Display Status Indications .....	65
Figure 62: Management Module Status Indications .....	66
Figure 63: Management Module LEDs .....	67
Figure 64: Port Numbering .....	68
Figure 65: Top and Bottom Ports .....	68
Figure 66: Management Module Interfaces .....	69
Figure 67: Reset Button .....	70
Figure 68: Spine Side Panel Display Status Indications .....	72
Figure 69: Management Module Status Indications for Normal Operation .....	72
Figure 70: Lock-down Bar .....	79
Figure 71: Face Plate Mounting Bolt Locations .....	80
Figure 72: Mechanical Lifting Device .....	81
Figure 73: Front Panel .....	87
Figure 74: Rear Panel Leaf Side of the Switch .....	88
Figure 75: InfiniBand QSFP Connector Symbol .....	90
Figure 76: QSFP Connector Male and Female Views .....	90

# Revision History

**Table 1 - Revision History of this User's Manual**

Revision	Date	Details
2.7	January 2014	Rearranged document: Consolidated installation sections under Chapter 2, "Installation," on page 15; updated Chapter 1, "Overview," on page 11; and re-ordered sections). Updated: <ul style="list-style-type: none"> <li>• Section 1.3, "Power Supply Redundancy," on page 14</li> <li>• Section 2.6.4, "Installing the Cable Holder," on page 40</li> <li>• Section 2.9, "Hot Swap Insertion and Extraction," on page 44</li> <li>• Section 7.1, "Disassembling the Chassis," on page 78</li> <li>• Appendix G, "Installation Safety Warnings," on page 93</li> <li>• Table 14, "IS5600 Switch Specification Sheet," on page 82</li> <li>• Appendix C, "Calculating the Power of a Chassis," on page 86</li> </ul>
2.6	Feb. 2012	Modified Section 7 to point to the SW UMs
2.5	July, 2011	Changed name to Hardware User Manual Fixed incorrect features list in Section 1.2
2.4	July, 2011	Changes to Reset button section.
2.3	June, 2011	Changes to installtion kit parts and procedure.
2.2	May, 2011	Removed "InfiniBand Fabric Initialization and Management" Updated Fabric Management Software Section
2.1	Nov. 2010	Added Barcode last page
2.0	Oct. 2010	Added air flow direction
1.9	Oct. 2010	Added procedure step to screw in 9 screws through the offset into the upper bracket. Fixed Port Connector LED Assignment.
1.8	Aug. 2010	Added weight lifting warning Added "Remove all protective plastic film from all sides and top of the chassis." Added FCC Statement 15.19 Added QSFP Cable Power Budget Classification Added Center of gravity numbers. Added Max Heat output numbers
1.7	June 2010	Fixed FabricIT screen grab.



**Table 1 - Revision History of this User's Manual**

Revision	Date	Details
1.6	June 2010	Added section on getting licenses Added note r.e. Wait 1 minute before putting in a Hotswap part. New power numbers Added appendix Calculate Custom chassis weight Added appendix Calculate Custom chassis power Added a note that if EFM is updated and the FW image in the leafs and spines is earlier than the minimum that the new version of EFM can work with then the chassis management system will require ~45 minutes to update all of the FW images in the leafs and spines. Replaced Directive WEEE graphic Added a note "...switches must be configured to 10/100M auto-negotiation" Moved Revision above About
1.5	April 2010	Minor formatting
1.4	April 2010	changed Appendix E OPNs
1.3	Mar. 2010	Updated Installation Section New Installation kit! Updated Cable holder figure
1.2	Jan. 2010	Updated Installation Parts Kit figure and parts table Updated Cable holder figure
1.1	Jan. 2010	Changed figure of the spine module
1.0	Dec. 2009	Initial Release

## About this Manual

This manual provides an overview of the SwitchX® based IS5600 modular InfiniBand chassis switch, and guidelines for its operation.

### Intended Audience

This manual is intended for users and system administrators responsible for installing and setting up the chassis platform.

The manual assumes familiarity with the InfiniBand® architecture specification.

## Related Documentation

The documentation set accompanying the QSFP Chassis InfiniBand Switch platform includes the following:

**Table 2 - Reference Documents and Websites**

Document Name	Description
InfiniBand Architecture Specification, Vol. 1, Release 1.2.1	The InfiniBand Architecture Specification that is provided by IBTA
Switch Product Release Notes	For possible hardware issues see the switch support product page. This requires a customer support login. Look up the relevant SwitchX®-based switch system/series release note file.
Mellanox MLNX-OS® User Manual for VPI	This document contains information regarding configuring and managing Mellanox Technologies SwitchX® switch platforms listing all of the commands available through MLNX-OS with explanations and examples.

## Conventions

Throughout this manual, the name IS5600 and the terms chassis and switch are used to describe the 648 port QSFP InfiniBand chassis, unless explicitly indicated otherwise.

The following icons are used throughout this document to indicate information that is important to the user.



This symbol makes recommendations to the user.



This symbol indicates information that is helpful to the user.



This symbol indicates a situation that can potentially cause damage to hardware or software.



Warning! This symbol indicates a situation that can potentially cause personal injury and / or damage to hardware or software.

# 1 Overview

This User Manual provides an overview of the IS5600 QSFP Modular InfiniBand Switch Platform (known in this document as ‘the chassis or switch’) and its operational environment.

Mellanox IS5600 switch systems provide the highest performing fabric solution by delivering high bandwidth and low latency to Enterprise Data Centers (EDC), High-Performance Computing (HPC) and Embedded environments. Networks built with the IS5600 system can carry converged traffic with the combination of assured bandwidth and granular quality of service. Built with Mellanox’s 4<sup>th</sup> generation InfiniScale® IV InfiniBand switch device, IS5600 systems provide up to 40Gb/s full bidirectional bandwidth per port. With up to 648 ports in a 31U rack space, these systems are among the densest switching systems available.

The switch platform comes pre-installed with all necessary firmware for standard operation within an InfiniBand fabric and requires an InfiniBand compliant Subnet Manager running from one of the hosts or the management module of the switch system. The initial configuration procedure should be followed to initialize the switch before connecting it to the network after which normal operation can proceed. (See the installation guide for details regarding the initial configuration.) Once connected to the network, the Subnet Management software automatically discovers and configures the fabric and begins utilizing the switch.

It is recommended that the Mellanox OpenFabrics software package be installed on all nodes connected to the switch. The software package provides a subnet manager and network management tools as well as connectivity software for servers and storage, and is available on the Mellanox web site.

Basic installation is covered in [Chapter 2, “Installation” on page 15](#).


Hot-swapping components and hardware maintenance is covered in [Chapter 2.9, “Hot Swap Insertion and Extraction” on page 44](#).

## 1.1 Product Information

### 1.1.1 Serial Number and Product Version Information

The serial number, GUID identifier and product version information are found on the label attached to the pull-out tab below the Mellanox logo on the spine side of the chassis.

**Figure 1: Product Label**




The GUID is the System Image GUID according to the IB spec. It is burned on the board which is in the chassis. All the boards and the management software look for this GUID in addition to their own Node GUID.


### 1.1.2 License Key

This chassis comes with a license for FabricIT-Chassis Manager. The license key to activate the license is found on the bottom side of the pull out tab.

**Figure 2: License Key Label**




**Figure 3: Product Label Tab Location**



### 1.1.3 Management Module MAC

Each management module has a label with its MAC address. See Figure 4 for the location of this label.

**Figure 4: Management Module MAC Address Location**



### 1.1.4 Product Physical Specifications and Power


The switch itself is 29U tall but requires an extra 2U for installing the shelf.

The switch ships in a minimum base configuration plus additional modules depending on the chosen customer configuration. Optional modules included:

- Leaf boards
- Management modules

The following figure shows the connector and spine sides fully populated.

**Figure 5: IS5600 Switch Views**



## 1.2 Features List

- 648 QDR (40Gb/s) InfiniBand ports in a 29U switch
- IBTA 1.2.1 compliant
- SDR/DDR/QDR link speed
- N+N power supply
- Congestion control <sup>1</sup>
- Adaptive routing<sup>1</sup>
- Port mirroring<sup>1</sup>
- Chassis High Availability
- sMB High Availability

## 1.3 Power Supply Redundancy

This chassis has N+1 power supply redundancy. With a full complement of power supplies, one power supply can be removed and replaced without shutting down the chassis or stopping the flow of data.

---

1. Features for a future release.

## 2 Installation



This chassis can be installed in standard 19" racks that have depths between 65cm and 80cm between the vertical supports of the rack.

Installation and initialization of the chassis is a simple process requiring attention to the normal mechanical, power, and thermal precautions for rack-mounted equipment. Your Chassis will be shipped in two packages one with the all of the leafs (leaf package) that are ordered and an extra management module should it be ordered, and the second package (chassis package) with all of the rest of the parts.

The chassis requires initial configuration to get the chassis and Fabric management up and running through remote management. See the Installation Guide that is packed in the box for the instructions to make the initial configuration.



This unit is intended for installation in a Restricted Access Location. A restricted access area can be accessed only through the use of a special tool, lock and key, or other means of security.

### 2.1 Installation Safety Warnings

These safety warnings are in English. For French, German, Spanish, Russian, and Romanian see the Appendixes.

#### 1. Installation Instructions




Read all installation instructions before connecting the equipment to the power source.

#### 2. Bodily Injury Due to Weight



Use enough people to safely lift this product.



#### 3. Heavy Equipment



This equipment is very heavy and should be moved using a mechanical lift to avoid injuries.

#### 4. Installation in Restricted Access Location



This unit is intended for installation in a Restricted Access Location.

#### 5. Risk of Electric Shock!



Risk of Electric Shock!

With the fan module removed power pins are accessible within the module cavity. DO NOT insert tools or body parts into the fan module cavity.

#### 6. Over-temperature



This equipment should not be operated in an area with an ambient temperature exceeding the maximum recommended: 45°C (113°F). Moreover, to guarantee proper air flow, allow at least 8cm (3 inches) of clearance around the ventilation openings.

#### 7. Stacking the Chassis



The chassis should not be stacked on any other equipment. If the chassis falls, it can cause bodily injury and equipment damage.

#### 8. Redundant Power Supply Connection - Electrical Hazard



This product includes a redundant power or a blank in its place. In case of a blank power supply, do not operate the product with the blank cover removed or not securely fastened.

#### 9. Double Pole/Neutral Fusing



This system has double pole/neutral fusing. Remove all power cords before opening the cover of this product or touching any internal parts.

#### 10. Multiple Power Inlets ,



Risk of electric shock and energy hazard.

The PSUs are all independent.

Disconnect all power supplies to ensure a powered down state inside of the switch platform.



## 11. During Lightning - Electrical Hazard



During periods of lightning activity, do not work on the equipment or connect or disconnect cables.

## 12. Copper InfiniBand Cable Connecting/Disconnecting



Copper InfiniBand cables are heavy and not flexible, as such they should be carefully attached to or detached from the connectors. Refer to the cable manufacturer for special warnings/instructions.

## 13. Rack Mounting and Servicing



When this product is mounted or serviced in a rack, special precautions must be taken to ensure that the system remains stable. In general you should fill the rack with equipment starting from the bottom to the top.

## 14. Equipment Installation



This equipment should be installed, replaced, and/or serviced only by trained and qualified personnel.

## 15. Equipment Disposal



Disposal of this equipment should be in accordance to all national laws and regulations.

## 16. Local and National Electrical Codes



This equipment should be installed in compliance with local and national electrical codes.

## 17. Installation Codes



This device must be installed according to the latest version of the country national electrical codes. For North America, equipment must be installed in accordance to the applicable requirements in the US National Electrical Code and the Canadian Electrical Code.

## 18. Battery Replacement



**Warning:** Replace only with UL Recognized battery, certified for maximum abnormal charging current not less than 4mA

There is a risk of explosion should the battery be replaced with a battery of an incorrect type.

Dispose of used batteries according to the instructions.

## 19. UL Listed and CSA Certified Power Supply Cord



For North American power connection, select a power supply cord that is UL Listed and CSA Certified, 3 - conductor, [16 AWG], terminated with a molded plug rated at 125 V, [13 A], with a minimum length of 1.5m [six feet] but no longer than 4.5m.

For European connection, select a power supply cord that is internationally harmonized and marked “<HAR>”, 3 - conductor, minimum 1.0 mm<sup>2</sup> wire, rated at 300 V, with a PVC insulated jacket. The cord must have a molded plug rated at 250 V, 10 A.

## 20. High Leakage Current



**Warning:** High leakage current; Earth connection essential before connecting supply.

## 21. Add GND connection information



Before connecting this device to the power line, the protective earth terminal screws of this device must be connected to the protective earth in the building installation.

(GND Connection Information):

The building installation shall provide a means for a connection to protective earth; and the equipment shall be permanently connected to that by a service person.

A SERVICE PERSON shall check whether or not the socket - outlet from which the equipment is to be powered provides a connection to the building protective earth. If not, the SERVICE PERSON shall arrange for the installation of a PROTECTIVE EARTHING CONDUCTOR from the separate protective earthing terminal to the protective earth wire in the building. The equipment shall be installed in area where equipotential bonding exists ((such as a telecommunication centre or a dedicated computer room).

## 22. Installation codes



This device must be installed according to the latest version of the country national electrical codes. For North America, equipment must be installed in accordance to the applicable requirements in the US National Electrical Code and the Canadian Electrical Code.

## 23. Interconnection Of Units



Cables for connecting to the unit RS232 and Ethernet Interfaces must be UL certified type DP-1 or DP-2. (Note- when residing in non LPS circuit)

**Overcurrent Protection:** A readily accessible Listed branch circuit overcurrent protective device rated 20 A must be incorporated in the building wiring.

## 24. Hazardous Radiation Exposure



Caution – Use of controls or adjustment or performance of procedures other than those specified herein may result in hazardous radiation exposure.




CLASS 1 LASER PRODUCT and reference to the most recent laser standards IEC 60 825-1:1993 + A1:1997 + A2:2001 and EN 60825-1:1994+A1:1996+A2:2001

## 25. Proper Enclosure




A suitable electrical, mechanical and fire enclosure shall be provided by the end product manufacturer and or the end user.

## 26. Do Not Use the Switch as a Shelf or Work Space



Caution: Slide/rail mounted equipment is not to be used as a shelf or a work space. The rails are not intended for sliding the unit away from the rack. It is for permanent installation at final resting place only, not used for service and maintenance

## 27. WEEE Directive



According to the WEEE Directive 2002/96/EC, all waste electrical and electronic equipment (EEE) should be collected separately and not disposed of with regular household waste.

Dispose of this product and all of its parts in a responsible and environmentally friendly way.

## 28. Country of Norway Power Restrictions



This unit is intended for connection to a TN power system and an IT power system of Norway only.

## 2.2 Environmental and Safety Recommendations

The following are Mellanox recommendations.



Recommended ambient temperature in the System room is  $20^{\circ} \pm 5^{\circ}$  C.  
Recommended humidity range is  $40\% \pm 15\%$  without condensing.



It is highly recommended that the installation sites be as isolated as possible from all sources of radio transmissions and electrical interference.



It is highly recommended that the installation site building be equipped with a lightning rod.



It is highly recommended that the installation site be equipped with smoke detectors and a fire alarm warning system.



The system requires a KVA rated UPS system. It is recommended that a UPS system be installed to protect the equipment in the event of unexpected power failure.



A fully loaded IS5600 switch system can draw 8 kW (~67A @ 120V or 34A @ 240V) of power. Make sure that the outlets and circuits will not be overloaded. Spread out the load over at least two or three circuits or use a 3 phase circuit.

## 2.3 Chassis Package Contents

The package includes:

- 1 chassis with the following modules installed:
  - 18 spines
  - 1 management module
  - 8 fans
  - 10 PSUs
- 1 installation guide
- 1 box containing various other parts
- 1 installation kit box
- 1 box containing 10 power cords 250v 15a 2.0M, C14 to C13, USA UL Standard
- 1 cable management kit

Before you install your new IS5600 series chassis, unpack the system and check to make sure that all the parts have been sent, check this against the parts list. Check the parts for

visible damage that may have occurred during shipping.



If anything is damaged or missing, contact your customer representative immediately.



The rack mounting holes conform to the EIA-310 standard for 19-inch racks. Guarantee proper ventilation, by leaving 8cm (3") of space to the front and rear of the switch. This will ensure proper air flow through the chassis. This is crucial for maintaining good airflow at ambient temperature. In particular, route cables such that they do not impede the air into or out of the chassis.

## 2.4 Leaf Package Contents

The leafs are ordered by the customer and are shipped 4 to a box. The customer will receive as many boxes as needed to fill the order.

## 2.5 Management Package Contents

When a second management module is ordered the package includes:

- 1 management module ordered by the customer
- 1 RJ45 to DB9 harness

## 2.6 Physical Installation



**Warning:** This equipment is very heavy. Safety is the first concern. Make sure that adequate manpower and proper equipment is used for transporting and moving the chassis.

The fully loaded chassis weighs:

327.15kg (721.24 LBS.) full configuration

128.97kg (284.33 LBS.) empty configuration

157.57kg (347 LBS.) shipped configuration

The switch platform uses 31U of rack space in a standard 19" rack, 29U for the chassis and 2U for the shelf. The switch ships from the factory with mounting holes on the spine side. There are upper brackets to connect the leaf side to the rack near the top of the chassis, and there are two lock-down bars to secure the chassis to the shelf. The weight of the switch is supported from underneath the unit by the shelf.

This chassis can be installed in standard 19" racks that have between 65cm and 80cm between the vertical supports of the rack. Make sure that a fully populated rack including cables will have sufficient air flow for cooling.



Choose a rack which is able to support the mechanical and environmental characteristics of a fully populated switch chassis.

## 2.6.1 Starting with the Rack

### 2.6.1.1 Rack Recommendation



Due to the space required by up to 648 connector cables Mellanox recommends a rack that is 120 cm long and 80cm wide. This will allow for proper cable management and enough ventilation to properly cool the chassis.



Mellanox recommends that you remove both sides of the rack to make the installation easier.




You will need a fork lift, to move and insert the chassis into the rack.

### 2.6.1.2 Preparing the Rack

The rack may need to be modified to accommodate the IS5600 chassis. The distance between the vertical supports must be between 65 and 80cm.

**Figure 6: Distance Between the Vertical Supports**



The vertical supports may have to be moved so that the vertical support closest to the door is a minimum of 6 cm from the inside of the door. This is required so that the shelf will not hit the door.



If you move the vertical supports make sure that you reinstall them vertically plumb.

## 2.6.2 ESD Connection

Before starting any procedure on the IS5600 switch system:

1. Put an ESD prevention wrist strap on your wrist, and make sure there is good contact between your body and the strap.
2. Plug the other end of the wrist strap to a valid ground. Make sure that this is a tight fit.

## 2.6.3 Installation Procedure



Installing the chassis will be a lot easier if you can remove the sides of the rack.



You will need a fork lift, to move and insert the chassis into the rack.

### 2.6.3.1 Requirements

You will need:

- #2 phillips screwdriver
- a fork lift
- measuring tape
- #3 phillips screwdriver
- a grounding lug
- ground wire of sufficient length and gauge to properly ground the chassis



The installation will be much easier with a power screwdriver.



It is recommended to use AWG6 or 4mm diameter wire for grounding purposes.




It is recommended to have at least two people for the duration of the installation procedure. Use a mechanical lift to raise this chassis. If not, use enough manpower to ensure the safety and wellbeing of all of the people involved in the installation.

### 2.6.3.2 Installation and Cable Management Kit Parts

- Parts included in the installation kit:
  - 1 shelf with brackets pre-installed
  - 1 left side upper bracket offset
  - 2 lock down bars
  - 1 shelf extension
  - 1 right side upper bracket offset
  - 2 upper bracket washers

- 8 lock washers for the upper brackets to vertical support
  - 12 hex head bolts – 8 for the upper brackets and 4 for the shelf extension
  - 34 pan head screws for the caged nuts 20 for the shelf and 14 for the chassis faceplate and 6 for the filler panels
  - 32 lock washers – 20 for the lock down bars and 12 for the upper brackets to upper bracket offsets
  - 2 upper brackets
  - 1 open end ratchet wrench 10mm
  - 1 socket wrench
  - 2 extensions for the socket driver
  - 4 flat washers for the shelf extension
  - Bottom filler panel
  - 1 nut Size M-8 for ground post
  - 34 caged nuts 20 for the shelf and 14 for the chassis faceplate and 6 for the filler panels
  - 32 hex head bolts – 20 for the lock down bars and 12 for the upper brackets to upper bracket offsets
  - 12 flat head screws for the upper bracket offsets
  - 1 socket nut driver 8mm
  - 1 socket nut driver 10mm
  - 1 socket nut driver 14mm
  - 1 box wrench
  - 6 two hole lock washers for lock down bars
  - Top filler panel
- Parts included in the cable management installation kit:
    - 1 cable management rack RH
    - 1 cable management rack LH
    - 16 caged nuts M6
    - 16 M6 bolts
    - 9 cable management shelves

**Figure 7: Installation Kit Parts**

### 2.6.3.3 Container Mishandling

The container has shock and tilt stickers applied. These will turn red if the container has been mishandled or roughly handled. Upon receipt of the container look for and inspect the shock and tilt stickers to confirm that they have not tripped. If one or more are red



notify the shipper and Mellanox. This on its own does not indicate damage to the contents. But, be sure to carefully inspect the contents if any of the shock and tilt stickers have tripped.


**Figure 8: Shock and Tilt Stickers**



### 2.6.3.4 Opening the Container

1. Before starting the procedure, put the ESD strap on and connect it to a valid ground.

**Figure 9: Container Screws**



It is highly recommended to have a screw gun or electric screwdriver for this step.

2. Remove the four sides of the container by unscrewing the phillips head screws holding the sides on.
3. Remove and put aside the box.
4. Visually inspect the chassis, make sure that:
  - there is no visible damage
  - all 18 spines are installed
  - 10 PSUs are installed for the chassis
  - all 8 fans are installed
  - 1 management module is installed
5. Remove all protective plastic film from all sides and top of the chassis.



The leafs are shipped separately.  
A second redundant management module, when ordered, is shipped separately.



Do not remove any of the blocks or either of the lock-down bars at this time.

### 2.6.3.5 Installing the Shelf



The chassis is on ball bearings and can roll easily. Be aware that the chassis can roll off of the pallet. **Should the chassis start to fall, move out of the way.** The chassis can cause grave bodily harm should it fall on or near you.

1. Select the location in the rack. Try to keep the chassis as low as possible to keep the center of gravity low.



It is recommended to set the top of the shelf at U5. Try and keep the chassis as low as possible. Set the shelf from U3 to U5.



Placing the shelf too low may make it impossible to tighten the shelf brackets, in step 11.

The maximum height that the chassis can be mounted, will be determined by the maximum height that the fork lift can raise the pallet.

2. Open the Installation kit and make sure that all of the parts are in the box. See Figure 7, “Installation Kit Parts”.


The chassis should sit in the rack with the spine side as close as possible to the door. This leaves maximum room for the cable management system.




The distance between the vertical supports must be between 65 cm(25.6”) and 80 cm(31.5”). If the distance in your rack is different, move the vertical supports so that one pair is ~10 cm(4in.) away from the door.



The side of the chassis with the spine units will sit flush with the vertical supports of the rack. The side of the chassis with the QSFP connectors will sit at the edge of the shelf closer to the center of the rack.

**Figure 10: Vertical Rack Supports Dimension**

3. Decide which side of the rack you want the data connectors.


**Figure 11: Placement of Chassis in Rack**

You will most likely need extra room for cable bending on the connector side of the chassis and should plan to keep the spine side as close to the rack door as possible, thus having more room for the cables.

4. Measure the distance between the vertical supports and adjust the shelf brackets according to this distance. This chassis can be installed in a rack with a distance between the vertical supports of from 65cm(25.6in.) to 80cm(31.5in.).

- The shelf comes with the four brackets pre-installed. Two of the brackets should be loose. They may need to be removed and repositioned to meet the distance between the vertical supports of the rack.

**Figure 12: Adjustable Shelf Brackets**





- Move the shelf brackets on the shelf. Place the shelf bracket so that it measures slightly more than the measured distance between the vertical rack supports. Make sure that there is enough play in the bracket so that it can move to the vertical support. **Do not tighten the hex head bolts.**




You may need to remove the brackets and reinstall them.

**Figure 13: Placing the Shelf Bracket**




**Figure 14: Caged Nut Locations for the Shelf Brackets**

7. Insert five nuts into the rack for each of the four shelf brackets (the 2 brackets that are adjustable and the 2 that are fixed). Make sure that the caged nuts are all at the same height on the vertical supports. **Do not use the top hole in the bracket.**
8. Insert 4 caged nuts (two on right and 2 on the left of the spine side) for the bottom filler panel.
9. Put the Shelf into the rack and twist the shelf into place. Make sure the spine side of the shelf is closest to the rack doors. See Figure 15 to identify the spine side of the shelf.
10. Install and tighten the 20 M6 bolts into the caged nuts.

**Figure 15: Shelf Brackets**

11. Tighten the 16 hex head bolts on the adjustable brackets.

**Figure 16: U Numbering Above Shelf**

12. Place 14 caged nuts into the vertical rack support at the locations corresponding to the holes in the chassis faceplate. The holes in the faceplate start at 2U above the shelf and are spaced every 4U centered as you go up the vertical rack support. There are 7 holes on each side.




### 2.6.3.6 Inserting the Chassis



The chassis is on ball bearings and can roll easily. Be aware that the chassis can roll off of the pallet. **Should the chassis start to fall, move out of the way.** The chassis can cause grave bodily harm should it fall on or near you.


1. Put the container on the fork lift.

**Figure 17: Putting the Chassis in the Rack Using a Fork Lift**




The chassis is screwed down to the pallet on both the spine side and the leaf side.


**Figure 18: Putting the Chassis in the Rack Using a Mechanical Lift**






**Figure 19: Place the Upper Bracket Offset**

2. Screw on the two Upper Bracket offsets onto the chassis using six flat head screws for each offset.

**Figure 20: Attach the Shelf Extension**

3. Screw on the shelf extension using four bolts with flat washers.

**Figure 21: Place Caged Nuts**



4. If you are installing the cable management system, place 14 caged nuts on the other side of the rack in the vertical supports.

**Figure 22: Location for the Lock-Down Bar**




5. Unscrew both lock-down bars.




With both lock-down bars removed the chassis can roll! Be very careful that the chassis does not roll off of the pallet.

6. Place the chassis in front of the rack and as close as possible to the rack.

**Figure 23: Fork Lift**



**Figure 24: Mechanical Lift**

7. Raise the chassis so that it is ~5cm above the shelf in the rack.
8. Raise the hinged extension on the container floor.
9. Lower the chassis until the hinged extension is sitting on the shelf extension.
10. Push the chassis from the container to the shelf.




Save the container pallet to remove this chassis. It will be necessary for the removal and disposal procedures.

**Figure 25: Face Plate Mounting Bolt Locations**

Holes in the faceplate for mounting on the rack.

The holes are separated by 4U units.





11. Slide the chassis onto the shelf and determine the location of the upper brackets, on the vertical supports on the connector side of the chassis.




Do not move the forklift away from the rack just yet.

12. Confirm that the caged nuts for the faceplate are in the correct location.
13. Slide the chassis out just far enough to install the upper brackets. See Figure 26.

**Figure 26: Upper Bracket Installation****Figure 27: Upper Brackets and Offset Location**

14. Screw the upper brackets onto the vertical supports and tighten in place. See Figure 27. You will need the socket wrench with both extensions to tighten these bolts.
15. Slide the chassis onto the shelf until the face plate of the chassis touches the vertical rack support.
16. Make sure the upper brackets are installed in their correct location.
17. Screw the 14 bolts through the faceplate into the caged nuts, DO NOT TIGHTEN.


**Figure 28: Offset to Upper Bracket Bolts**

18. For each offset and upper bracket, screw six bolts through the offset into the upper bracket. See Figure 28. Use one flat washer and one lock washer for each of these bolts. DO NOT TIGHTEN.

**Figure 29: Location for the Lock-Down Bar**



**Figure 30: Lock-Down Bar**




19. Place the front lock-down bar at the edge of the chassis and align the holes in the lock-down bar with the holes in the shelf. Screw down the lock-down bar. You will need the 10 hex head screws and washers for each lock down bar. DO NOT TIGHTEN
20. Screw down the second lock-down bar.

**Figure 31: Lock-Down Bars Bolt and Washer Order**



21. Remove the shelf extension and save for removal of the chassis.
22. Connect a valid ground, See Section 2.6.5, “Ground Connections,” on page 41, for detailed instructions.
23. Tighten the faceplate screws. See Figure 25 on page 36.
24. Tighten the upper bracket to upper bracket offset screws. See Figure 28.
25. Tighten the lock down bars. See Figure 31.
26. Connect the bottom filler panel below the shelf, bend facing out.
27. Connect the top filler panel directly above the top of the chassis.

**Figure 32: Spine Side with Filler Panels**




28. Go to Chapter 4, “Chassis Power Up,” on page 71 to power up the switch system.
29. Insert 2 caged nuts for the filler panel.

## 2.6.4 Installing the Cable Holder



Now is the time to install the cable holder.

**Figure 33: Cable Holder**





1. Place the cable holder next to the rack, on the connector side of the chassis, and identify the holes where the caged nuts were placed in step 4



The cable holders should go to the outside of the vertical supports.

2. Set the bottom of the cable holder at the level of the shelf.



If the cable holder is not set properly the upper bracket will not line up with the cable holder.

3. Screw the cable holder onto the rack using the screws provided.
4. Repeat steps 1- 3 for the second cable holder.
5. Install the shelves. The cable support shelves just sit on the cable holders.
6. Use the holes in the shelves to tie down the cables individually or in bundles.



Use Velcro ties to tie down the cables. Electric cable ties are not recommended.

## 2.6.5 Ground Connections

Make sure to connect the ground post to a valid electrical ground. Use a grounding lug and a ground wire of sufficient capacity to safely convey a potential discharge. The grounding post is M-8 with 1.25mm pitch threads. A ground wire of AWG 6 or 4mm diameter is recommended for grounding this device. The chassis is concurrently grounded through each of the PSUs. Only connect the PSU cords to properly grounded outlets. Do not rely on the PSU grounds. It is absolutely necessary to connect the grounding post. Make sure the connections are solid and permanent. If you choose to not use the ground screw, make sure that the rack is properly grounded and that there is a valid ground connection between the chassis of the switch and the rack. Test the ground using an Ohm meter.

**Figure 34: Ground Connection**



## 2.7 Power Connections

The switch includes integrated hot-swap power supplies which support up to 10 load-sharing 1000W. The slots for the power supply units (PSUs) are on the spine side. The

left side has odd numbered PSUs and the right side has even numbered PSUs. Each PSU has a dedicated AC inlet. This design enables the optional use of separate main and backup AC feeds. The input voltage is Autorange, 100-240 VAC, 50Hz or 60Hz. The output voltage for the PSUs is 48V. The power cords should be standard 3-wire AC power cords including a safety ground.

## 2.7.1 Powering Up the Switch Platform



Make sure that the power cords are compatible with your outlets. Power cords for different countries can be ordered from Mellanox.

The chassis in N+1 mode must be started with a full complement of PSUs, thereafter it can run on one less than the total number of PSUs. This final PSU is redundant and allows for hot swapping a PSU should one fail. Connecting the PSUs to different AC lines provides AC failover protection.

The system should continue to run and allow a hot swap of a defective PSU. Should there not be enough power to keep all of the leafs running, FabricIT EFM may power down some leafs. If this happens it may be necessary to reboot the chassis once the defective PSU has been replaced. Two simple ways to reboot is to use the reboot command in the CLI or reboot through the Web GUI.

The power system will divide the current consumption by the number of working PSUs. Should one of the PSUs fail, the total current consumption will then be divided by the remaining working PSUs. When the failed PSU is hot swapped the new PSU will ramp up and pass its share of current, so that the total current is always divided by the number of working PSUs.

1. Plug in the power cords to the PSUs.
2. Plug the other end of the power cords into grounded outlets.



A fully loaded IS5600 switch system can draw 8 kW (~67A @ 120V or 34A@240V) of power. Make sure that the outlets and circuits will not be overloaded. Spread out the load over at least two or three circuits or use a 3 phase circuit.

**Figure 35: Multiple Power Inlets – Electric Caution Notification**

CAUTION	ACHTUNG	ATTENTION
Risk of electric shock and energy hazard. The PSUs are all independent.	Gefahr des elektrischen Schocks. Entfernen des Netzsteckers elnes Netzteils spannungsfrei. Um alle Einheiten spannungsfrei zu machen sind die Netzstecker aller Netzteile zu entfernen	Risque de choc et de danger e'lectriques. Le de'branchment d'une seule alimentation stabilise'e ne de'branch uniquement qu'un module "Alimentation Stabilise'e". Pour isoler completely le module en cause, Il faut de'brancher toutes les alimentations stabilise'es.
Disconnect all power supplies to ensure a powered down state inside of the switch platform.		

3. Check the Status LEDs on all of the management modules and confirm that all of the LEDs show status lights consistent with normal operation.



Any yellow or red status LEDs on any of the management modules is cause for concern and must be dealt with immediately.

4. Check that none of the LEDs on the spines are yellow.




It can take up to 5 minutes to boot up the system. Turn off the system if any LEDs remain red for more than 5 minutes.

5. Check that the leaf status LEDs, fan status LED, and spine status LED in the spines are all green.



The maximum number of connections from each leaf is 1. If the (number of leafs x the maximum number of connections per leaf) is less than 36 then some of the leaf to spine connection LEDs may be OFF.

**Figure 36: Spine Module**



## 2.8 InfiniBand QSFP Cable Installation

The switch uses industry standard QSFP InfiniBand cables which are available from several vendors. The standard QSFP cables support full 40+40Gb/s (QDR), 20+20Gb/s (DDR) and 10+10Gb/s (SDR) bidirectional wire speed of the switch ports. All InfiniBand QSFP connections are made to the leaf boards. Each leaf has 18 InfiniBand QSFP connectors in two rows, which are numbered 1-18. See Section 3.1.6 for port numbering.



If maximum cable lengths are exceeded data transfer will be reduced and the bit error rate will increase.

All cables can be inserted or removed with the unit powered on. To insert a cable, press the connector onto the port receptacle until the connector is firmly seated. The orange LED indicator above the port will light when the physical connection is established (when both ends of the cable are properly connected to working devices). Allow 15 sec-

onds for link to get up. To remove, disengage the lock and slowly pull the connector away from the port receptacle.



For a valid physical connection both ends of the cable must be connected to working devices.



Take care to not impede the air flow through the ventilation holes next to the InfiniBand ports. Use cable lengths which allow routing horizontally around to the side of the chassis before bending upward or downward in the rack.

### 2.8.1 Supported Approved Cables

For a list of approved cables for this switch see the Mellanox approved cable list.

[http://www.mellanox.com/related-docs/user\\_manuals/Mellanox\\_approved\\_cables.pdf](http://www.mellanox.com/related-docs/user_manuals/Mellanox_approved_cables.pdf)

### 2.8.2 Cable Power Classes

Chassis and switches need to be able to dissipate the heat generated by high power I/O cables and modules. The Mellanox IS5x00 series chassis are rated for cables up to class 2 as per the SFF committee classification ([SFF-8436.PDF](#)).

See <http://www.mellanox.com/content/pages.php?pg=cables> for the cable class rating of Mellanox cables.

## 2.9 Hot Swap Insertion and Extraction

Before starting any procedure on the IS5600 switch system, put an ESD prevention wrist strap on your wrist and connect to the IS5600 chassis.



Do NOT mix replacement parts based on different generations of chip.  
Do not install InfiniScale IV based replacement parts within a SwitchX® based chassis and vice versa. All Replacement modules must be consistent with the Chassis family and switch chip generation.



When hot-swapping any of the units, it is necessary to wait 1 minute after removing the defective part before inserting the new part. This is necessary so that the management module will start a new cycle checking through the leafs and spines for the FW versions.

This switch platform supports hot swap capabilities for the parts listed below.

- Power supply units
- Leaf boards
- Spine boards
- Leaf fan module
- Spine fan module
- Management modules


## 2.9.1 Power Supply Units

### 2.9.1.1 Extracting and Inserting the Power Supply Unit


➤ *To extract a PSU:*

1. Determine which AC connector on the connector side of the chassis corresponds to the defective PSU.
2. Remove the power cord from the power supply unit. Note which power cord it is according to the AC numbering.

**Figure 37: Power Cord Numbering**




**Figure 38: PSU and Outlet Locations**



3. On the spine side of the chassis, remove the cover to the power supply unit for the non-working PSU. Odd numbered PSUs are on the left side and even numbered PSUs

are on the right side facing the spines. There are four phillips head screws for the cover plate.

**Figure 39: Power Supply**



4. Grasping the handle with one hand, push the black latch release while pulling the handle outward. As the PSU unseats, the PSU status indicators will turn off.

5. Remove the PSU.

➤ **To insert a PSU:**

1. Make sure the mating connector of the new unit is free of any dirt and/or obstacles.
2. Insert the PSU by sliding it into the opening until a slight resistance is felt.
3. Continue pressing the PSU until it seats completely. The latch will snap into place confirming the proper installation.
4. Insert the power cord into the supply connector on the other side of the chassis.
5. Replace the cover over the PSUs.



The green indicators should light. If not, extract the PSU and re-insert it again.

## 2.9.2 Leaf Boards



Do NOT mix replacement parts based on different generations of chip. Do not install InfiniScale IV based replacement parts within a SwitchX® based chassis and vice versa. All Replacement modules must be consistent with the Chassis family and switch chip generation.




When hot-swapping any of the units, it is necessary to wait 1 minute after removing the defective part before inserting the new part. This is necessary so that the management module will start a new cycle checking through the leafs and spines for the FW versions.

The leaf boards are numbered from top to bottom, with corresponding numbers displayed to the outside of the leafs vertically along the side panel.



### 2.9.2.1 Extracting a Leaf Board




Each leaf board has an ejector handle that locks the board in place and serves as a lever for seating or extracting (see Figure 40).

1. Run the shut down command "no power enable <module>". For example to shut down leaf 16 run the command below.

```
switch [master] (config) # no power enable L16
```

2. Disconnect all cables connected to the leaf.
3. Push the ejector handle to unlock the ejector from the chassis.
4. Open the ejector until it is 45 degrees from the leaf.

**Figure 40: Ejector Handle**



5. Pull out the module half-way through the guiding rails using the ejector handle.
6. Lock the ejector handle.

7. Hold the body of the leaf on both sides and remove it from the chassis.




The board is short, therefore do not let go of it while sliding it out.

**Figure 41: Leaf Release**

Push here to release the ejector handle

Pull the ejector handle to remove the leaf



### 2.9.2.2 Inserting a Leaf Board




When hot-swapping any of the units, it is necessary to wait 1 minute after removing the defective part before inserting the new part. This is necessary so that the management module will start a new cycle checking through the leafs and spines for the FW versions.

To insert the leaf board:

1. Check for foreign objects in or mechanical damage to the chassis leaf slots.
2. Check leaf mechanics for any noticeable damage.
3. Check back signal connectors' integrity. Look for any broken signal dividers or any deviations from the pass criterion shown in Figure 42.


**Figure 42: Intact vs Defected Signal Connectors**





4. Check power connector's integrity. Look for any damage on the power connector casing or blades damage, or any deviations from the pass criterion show in Figure 43.

**Figure 43: Intact vs Defected Power Pin Holders**



5. Start with the ejector handle fully open; that is, at 45 degrees to the front panel of the leaf.
6. Holding the leaf by its sides, carefully set the leaf board into the chassis.
7. Applying equal pressure on both sides of the leaf board, slowly slide the board into the chassis until the ejector handle reaches the vertical bar.



Do not apply excessive force to slide in the leaf board. If you feel resistance, remove the leaf board and double check both the chassis and leaf for any damage.

8. Catch the hook onto the vertical bar of the chassis and push the ejector handle shut.
9. Lock the ejector handle onto the board.

## 2.9.3 Spine Boards



Do NOT mix replacement parts based on different generations of chip. Do not install InfiniScale IV based replacement parts within a SwitchX® based chassis and vice versa. All Replacement modules must be consistent with the Chassis family and switch chip generation.



When hot swapping any of the units, it is necessary to wait 1 minute after removing the defective part before inserting the new part. This is necessary so that the management module will start a new cycle checking through the leafs and spines for the FW versions.

Each spine has a pair of ejectors that lock the board in place and serve as levers for seating or extracting (see Figure 45).

Management board #1 is connected to spine board #1, and management board #2 is connected to spine board #2. **When a slave management board is not installed or not working, the spine board connected to the master management board cannot be hot-swapped.** All of the spine boards can be hot-swapped when two management boards are installed and working.



When more than one spine slot is empty always insert the lowest spine board first, then work your way up.



If you need to replace the bottom spine and it does not go in, try removing one or two spines above it and then insert the spines from the bottom up.

### 2.9.3.1 Extracting a Spine Board




When a slave management board is not installed or not working, hot-swapping the spine board connected to the master management board will cause the chassis to crash.



Neither the CLI nor the GUI management tools will allow you to shut down spine #1 or spine #2, as the management modules are connected to the chassis components through these spines.

#### Extracting Spine Board #1 or #2

Spine board #1 is connected to management board #1 and spine board #2 is connected to management board #2.

**Figure 44: Management Module Numbering**

MNG1 management module #1  
(top)  
MNG2 management module #2  
(bottom)




Removing spine #1 causes management module #1 to reset.  
Removing spine #2 causes management module #2 to reset.



**Warning:** If the spine you want to hot swap is connected to the **master** management module the management module will **reboot** when you take out the spine.  
**If you have only one management module the chassis will crash!**

**Figure 45: Spine Board Extraction**

Pull the latches to remove the spine.



If you need to hot swap spine #1 or spine #2:

1. Check to see if the spine you need to remove is connected to the master management module. See Figure 44.



If you have only one management module, the chassis will crash!

2. Follow the steps in Section below.

### Extracting Spine Boards Except #1 or #2

1. Run the shut down command "`no power enable <module>`". For example to shut down spine 06 run the command below.

```
switch [master] (config) # no power enable S06
```

2. Push outward on the ejector handles to unlock the ejectors from the chassis.

3. Open the ejectors until they are at a 45 degree angle from the module.



Do not use the fan FRU handle to extract the spine board.

4. Pull out the module half-way through the guiding rails using both ejectors.
5. Lock the ejector handles.
6. Hold the body of the board on both sides and remove it from the chassis.

### 2.9.3.2 Inserting a Spine Board




When hot-swapping any of the units, it is necessary to wait 1 minute after removing the defective part before inserting the new part. This is necessary so that the management module will start a new cycle checking through the leafs and spines for the FW versions.

To insert a spine board:

1. Check for foreign objects in or mechanical damage to the chassis spine slots.
2. Check spine mechanics for any noticeable damage or deviations from the pass criterion shown in Figure 46.


**Figure 46: Intact vs Defected Mechanics**






3. Check back signal connectors' integrity. Look for any broken signal dividers or any deviations from the pass criteria shown in Figure 47 and Figure 48.

**Figure 47: Intact vs Defected Side Signal Connectors**




**Figure 48: Intact vs Defected Middle Signal Connectors**



4. Check power connector's integrity. Look for any damage on the power connector casing or blades damage, or any deviations from the pass criterion shown in Figure 49.

**Figure 49: Intact vs Defected Power Pin Holders**



5. Start with the ejector handles fully open; that is, at 45 degrees to the front panel of the spine.



Do not use the fan FRU handle to insert the spine board.

6. Holding the spine by its sides, carefully set the spine board into the chassis.
7. Using only the ejector handles, slowly slide the board into the chassis until the hooks reach the vertical bar.



Do not apply excessive force to slide in the spine board. If you feel resistance, remove the spine and double check both the chassis and spine for any damage.

8. Catch the hooks onto the vertical bar of the chassis and push the ejector handle shut.
9. Lock the ejector handles onto the board.

## 2.9.4 Fan Modules

There are eight fan modules on the chassis for the leafs. They are located on both sides of the chassis; four on the leaf side corners and four on the spine side corners. When a fan module is not functioning the status LED on the fan will light up.

Each spine has an individual fan module that contains two individual fans. Should a single fan fail the Fan Status LED on the spine and the S. Fan LED on the management module will light, indicating the necessity to replace the fan module. Air flow through the spines is independent of the air flow through the leafs.




There are two different fan modules for the chassis. These fans have different model numbers and are not interchangeable. The fans on the leaf side of the chassis are MTF005001, whereas the fans on the spine side of the chassis are MTF005002.


### 2.9.4.1 Leaf Fan Module

There are eight Leaf fan modules. Four leaf fan modules are found on the leaf side and four leaf fan modules are found on the spine side.

The leaf side fans are not interchangeable with the spine side fans. Air flow through the leafs is independent of the air flow through the spines.

**Figure 50: Leaf Fan Locations on the Chassis****Extracting the Leaf Fan Module**

1. Push and hold the blue latch release. See Figure 51.
2. Slowly pull out the fan module using the handle.

**Figure 51: Leaf Fan Module Extraction**

## Inserting the Leaf Fan Module



When hot-swapping any of the units, it is necessary to wait 1 minute after removing the defective part before inserting the new part. This is necessary so that the management module will start a new cycle checking through the leafs and spines for the FW versions.

1. Make sure the fan module is oriented correctly top side up. Confirm that the location of the connector in the chassis will line up with the connector in the fan module.
2. Slowly slide in the new leaf fan module.




If the fan module stops before it goes in all of the way it is inserted incorrectly or it may be for the other side of the chassis!

3. Push the fan module until the latch engages.
4. Make sure that the green leaf LED on the module comes on (indicating that fan is running).

### 2.9.4.2 Spine Fan Modules

Each spine module has a fan module with two individual fans built in. When a fan module is not functioning the Fan Status LED on the spine will light up.


**Figure 52: Spine Fan Module**



Fan module

When a fan module is removed the indicator light will reset.

**Figure 53: Fan Status LED on the Spine Module**



### Extracting the Spine Fan Module

1. Push the two blue latch buttons together while pulling the fan module out.



## Inserting the Spine Fan Module



When hot-swapping any of the units, it is necessary to wait 1 minute after removing the defective part before inserting the new part. This is necessary so that the management module will start a new cycle checking through the leafs and spines for the FW versions.

1. Make sure the fan module is oriented correctly top side up. Confirm that the location of the connector in the chassis will line up with the connector in the fan module.
2. Slowly slide in the new spine fan module.
3. Push the fan module as far as it will go, make sure the locking latches engage.



If the Fan LED continues to show red remove the fan module and check the pins on the connector inside of the spine to make sure that none of them are bent.

### 2.9.5 Management Module



When hot-swapping any of the units, it is necessary to wait 1 minute after removing the defective part before inserting the new part. This is necessary so that the management module will start a new cycle checking through the leafs and spines for the FW versions.

## Extracting a Management Module

Management modules are located on the leaf side, above the leafs. There are two places to install the management modules.



Only one management module is required to run the switch system.

Each management module has a pair of ejectors that lock the board in place and serve as a lever for seating or extracting (see Figure 54).

1. Run the shut down command **"no power enable <module>"**. For example to shut down management module 2 run the command below.

```
switch [master] (config) # no power enable MGMT2
```


2. Disconnect all cables connected to the management module.
3. Push outward on the ejector handles to unlock the ejectors from the chassis.
4. Open the ejectors until they are 45 degrees from the module.
5. Pull out the module half-way through the guiding rails using the ejector handle.
6. Lock the ejector handle.

7. Hold the body of the board on both sides and remove it from the chassis.



The board is short, therefore do not let go of it while sliding it out.

**Figure 54: Management Module**



### 2.9.5.1 Inserting a Management Module




When hot-swapping any of the units, it is necessary to wait 1 minute after removing the defective part before inserting the new part. This is necessary so that the management module will start a new cycle checking through the leafs and spines for the FW versions.

To insert a management board:


1. Check for foreign objects in or mechanical damage to the chassis management slots.
2. Check management mechanics for any noticeable damage.
3. Check back signal connectors' integrity. Look for any broken signal dividers or any deviations from the pass criterion shown in Figure 55.

**Figure 55: Intact vs Defected Signal Connectors**



4. Check power connector's integrity. Look for any damage on the power connector casing or blades damage, or any deviations from the pass criterion shown in

Figure 56.



5. Start with the ejector handles fully open; that is, at 45 degrees to the front panel of the management.
6. Holding the management by its sides, carefully set the management board into the chassis.
7. Using only the management ejector handles, slowly slide the board into the chassis until the hooks reach the vertical bar.



Do not apply excessive force to slide in the management board. If you feel resistance, remove the management and double check both the chassis and management for any damage.

8. Catch the hooks onto the vertical bar of the chassis and push the ejector handle shut.
9. Lock the ejector handles onto the board.



On switch systems with dual management systems, first connect the cable and configure the master management module CPU and only then configure the slave. By default the master CPU is the top management module. For further information on the master and slave roles, see the FabricIT EFM Software UM section “High Availability”.



All management modules in the chassis must go through an initial configuration procedure. See the Installation Guide for the initial configuration procedure.

## 2.9.6 Switch Shut-Down Procedures

To shut down the chassis run the following command twice (once for each MM):

```
Reload halt [noconfirm]
```

**The chassis cannot be restarted remotely!**

To restart the chassis you must physically go to the switch and unplug all of the power cords to the chassis and then replug in all of the power cords to the chassis.

The first time you run the command it shuts down the master management module and the second time shuts down the slave management module.

To shut down a leaf run the following command:

```
no power enable <module>
```

To shut down a spine run the following command:

```
no power enable <module>
```

To shut down a management module run the following command:

```
no power enable <module>
```

## 3 Interfaces

### 3.1 LED Status Indicators

The LEDs are placed on the chassis for the convenience of the IT manager. All chassis conditions and management options are available and controllable through the management SW, either CLI or Web GUI.




It is recommended that all of the chassis sub systems be maintained and managed through the management software.

#### 3.1.1 Power Supply Unit LEDs

Each Power Supply Unit has the following indicator LEDs.

**Figure 57: Power Supply Unit Status Indications**



AC – When lit this LED indicates input voltage between 100 and 240 Volts.


DC FAIL – When lit this LED indicates a fault in the power supply.

DC OK – When lit this LED indicates that the output from the power supply is +48 VDC.




The PSUs are on the spine side of the chassis behind two cover panels. The plugs for these PSUs are on the leaf side of the chassis.

**Figure 58: PSU Cover On and Off**



### 3.1.2 Leaf Board LED Indicators

**Figure 59: Leaf Board Led Indicators**



#### 3.1.2.1 Status LED

Each leaf board has a Status LED on the far left of the leaf. Table 3 shows the leaf status according to the LED condition.

The Leaf Status indicator LED has the following LED assignment:

**Table 3 - Leaf Status LED**

LED Condition	LED Description
Off	No power to the Leaf

**Table 3 - Leaf Status LED**

LED Condition	LED Description
Solid Green	Leaf is up and running
Flashing Green	Leaf is powering up
Solid Orange	Non fatal error – this leaf needs troubleshooting, but does not require chassis shutdown
Solid Red	Fatal error

### 3.1.2.2 Leaf Board Port Connector LED Assignment

Above the ports are two LEDs one for the upper port ▲ and one for the lower port ▼. Each port has a single 2 color LED. Table 4 shows the link status according to the LED condition.

**Table 4 - Connector Physical and Logical Link Indications**

LED Condition	LED Description
Off	No power to the port
Solid Green	Logical link up
Flashing Green	Data activity – flashing speed is proportional to data transfer speed
Solid Orange	Physical link up
Flashing Orange	A problem with the physical link

The LED indicator, corresponding to each data port, will light orange when the physical connection is established (that is, when the unit is powered on and a cable is plugged into the port with the other end of the connector plugged into a functioning port). When a logical connection is made the LED will change to green. When data is being transferred the light will blink green.



The switch does not provide a visual means to indicate the port speed configuration (SDR, DDR, QDR) and/or the link width (1X or 4X). The speed and link width configurations can be retrieved using management software.

### 3.1.3 Spine Board LED Indicators


Each leaf board is connected by links to each spine module. Each spine has the following LEDs.

- One status LED for the spine health
- One status LED for the spine fan modules
- 36 status LEDs showing the existence of leaf to spine connections

The 36 LEDs on each spine are divided by the number of leafs and the result (N) is the number of connections from each leaf that are connected to the spine. 18 spines must be installed and working to ensure that full BW exists between nodes. The maximum number of connections from each leaf is 1. If the (number of leafs) x (the maximum number

of connections per leaf) is less than 36 then some of the leaf to spine connection LEDs may be OFF.

The status LEDs for the spine and their descriptions are shown in Table 5. The LEDs indicate as follows.



### 3.1.3.1 Status LED

Table 5 shows the spine status according to the LED condition.

**Table 5 - Spine Status LED**

LED Condition	LED Description
Off	No power to the spine
Solid Green	Spine is up and running
Flashing Green	Spine is powering up
Solid Orange	Non fatal error – this spine needs troubleshooting, but does not require chassis shutdown
Solid Red	Fatal error

### 3.1.3.2 Fan LED

The spine fan indicator LED has the following LED assignment:

**Table 6 - Spine Fan Status LED**

LED Color	LED Description
Solid Green	Spine Fan is OK
Flashing Green	Spine Fan needs replacing
Solid Yellow	One or more of the fans in this spine is not working Each spine has two fans in the fan module

### 3.1.3.3 Spine to Leaf IB Connection Status LEDs

The leaf connection status on each spine displays the condition of the connection between the spine and each leaf. There is a minimum of one LED per leaf per spine and a maximum of 1 LED per leaf. These LEDs indicate a valid connection between a leaf and a spine.



Table 7 shows the leaf to spine status according to the LED condition.

**Table 7 - Spine to Leaf IB Link Status**

LED Condition	LED Description
Off	Link is down
Solid Green	Logical connection
Flashing Green	Data activity
Solid Orange	Physical connection

### 3.1.4 Spine Side Panel Display LED Indicators

The spine side panel display has LEDs that show the chassis condition.

**Figure 61: Spine Side Panel Display Status Indications**



**Table 8 - LEDs Display for Normal Operation**


LED Condition	Description	Normal State
STATUS	Off – No Power Green – System is up and running Yellow – System warning. Attention needed (such as overheating) Red – System not operational (Diagnostics fail, CPU hang, HW fail, Overheat-critical) Blinking green – System booting / Restore factory defaults in progress	Green
PSU STATUS	Off – No power Green – Normal operational Red – PS fault detected. User should check individual power supplies for fault indications.	Green
SPINE FANS STATUS	Off – No power to fan Green – Nominal operational Red – One or more of the spine fans is bad. User should check individual spine fan LEDs for fault indications.	Green
LEAF FANS STATUS	Off – No power to fan Green – Nominal operational Red – One or more of the leaf fans is bad. User should check individual leaf fan LEDs for fault indications.	Green

**Table 8 - LEDs Display for Normal Operation**

LED Condition	Description	Normal State
MNG1 MASTER STATUS	Off – - no power - this management module is not installed - this management module is not the master  Green – Management module is operating as a master	Green
MNG2 MASTER STATUS	Off – - no power - this management module is not installed - this management module is not the master  Green – Management module is operating as a master	Off

### 3.1.5 Management Module LED Indicators

**Figure 62: Management Module Status Indications**




The management module LEDs display the switch system operating conditions.

**Table 9 - LEDs Display for Normal Operation**

LED Condition	Description	Normal State
STATUS This LED shows the status of the chassis.	Off – No Power Green – System is up and running. Yellow – System warning. Attention needed (such as overheating). Red – System not operational (Diagnostics fail, CPU hang, HW fail, Overheat-critical) Blinking green – System booting / Restore factory defaults in progress.	Green
PSU STATUS	Off – No power Green – Normal operational Red – PS fault detected. User should check individual power supplies for fault indications.	Green
SPINE FANS STATUS	Off – No power to fan Green – Nominal operational Red – One or more of the spine fans is bad. User should check individual spine fan LEDs for fault indications	Green

**Table 9 - LEDs Display for Normal Operation**

LED Condition	Description	Normal State
LEAF FANS STATUS	Off – No power to fan Green – Nominal operational Red – One or more of the leaf fans is bad. User should check individual leaf fan LEDs for fault indications	Green
MASTER	Off – this management module is not the master MM Green – Management module is operating as a master (i.e., the other management module is a slave)	Green

**Figure 63: Management Module LEDs****3.1.5.1 Management Module PSU LED Indicator**

The management module PSU indicator should be green.

**Table 10 - Management Module PSU LED Configurations**

LED Condition	Description
Green	OK – All PSUs are working at correct input and output voltages.
Red	Error – One or more of the PSUs for the chassis is bad. Check each PSU for a red LED.

**3.1.5.2 Management Module S. FANS LED Indicator**

The management module S. FANS indicator should be green.

**Table 11 - Management Module S.Fan LED Configurations**

LED Condition	Description
Green	OK – All Spine fans are working at configured speed.
Red	Error – One or more of the spine fans within a spine fan module is bad. Check the spines for a flashing green fan LED.

### 3.1.5.3 Management Module L. FANS LED Indicator

The management module L. FANS indicator should be green.

**Table 12 - Management Module L.Fan LED Configurations**

LED Condition	Description
Green	OK – All Chassis Leaf fans are working at configured speed.
Red	Error – One or more of the leaf fans for the chassis is bad. Check each chassis fan for a red LED.

### 3.1.5.4 Management Module MASTER LED Indicator


**Table 13 - Management Module MASTER LED Configurations**

LED Condition	Description
Green	This management module is the master.
Off	This management module is the slave.


### 3.1.6 Port Connector Interfaces

The connector side of the switch has 36 leaf boards and each leaf board has 18 QSFP ports. The ports on each leaf board are placed in two rows, 9 ports to a row. The ports are labelled as shown in Figure 64. The bottom row ports are flipped from the top row. See Figure 65.

**Figure 64: Port Numbering**



**Figure 65: Top and Bottom Ports**



## 3.2 Air Flow

These switches come with the air flow pattern of air entering through the spine side and exiting through the connector side.

## 3.3 QSFP Cable Power Budget Classification


All IS5600 QSFP switches are designed for active cables with a max power per module of 2.0W. This is power level 2 according to the QSFP Public Specification.

## 3.4 Management Module Interfaces

The switch system requires at least one management module. The management module has five interfaces to connect to the IS5600. They are:

- 1 I2C port
- 1 CONSOLE port – this is an RS232 connector for connecting to a host machine
- 1 MGT – this is an Ethernet connector
- 1 USB port
- 1 RST – reset button

**Figure 66: Management Module Interfaces**



### 3.4.1 I2C



This interface is for Debug and Troubleshooting only. This interface is for FAEs only.

### 3.4.2 CONSOLE

The CONSOLE port is used during the installation process to configure the chassis for remote management. Connect this port to a local host using the harness supplied with the chassis. See the Installation Guide for the initial configuration procedure.

### 3.4.3 MGT– Management

The MGT port is an Ethernet port for remote management. Any remote terminal connected to the Ethernet port can then be used to manage the fabric and chassis.



Each Ethernet connector gets connected to Ethernet switches. These switches must be configured to 100M auto-negotiation.



Initial configuration must be done on all of the management modules. The first management module you configure will be the master.

### 3.4.4 USB

The USB port can be used to upload new SW using any storage device that has a USB connector. This interface is USB 2.0.


### 3.4.5 Reset – RST

The Reset button resets the chassis management module when the button is pushed. When the button is held down for 15 seconds the management module is reset and the password deleted.



DO NOT use a sharp pointed object such as needle or push pin for pressing the Reset button. Sharp objects can cause damage, use a flat object such as a paper clip.

**Figure 67: Reset Button**



This button resets the CPU of the management module. A quick push of this button performs this reset. When the reset button is pushed on the master management module this management module is reset becoming the slave and the other management module becomes the master. If there is only one management module in the chassis all of the leafs and ports are reset by bringing them down and powering them up when the reset button is pushed. When the button is held down for 15 seconds the management module is reset and the password is deleted. You will then be able to enter without a password and make a new password for the user “admin”.

## 4 Chassis Power Up



Before starting any procedure on the IS5600 system put an ESD prevention wrist strap on your wrist and connect to the IS5600 chassis.

With N+1 PSU redundancy the chassis must be started with a full complement of possible PSUs, thereafter it can run on one less than the total number of PSUs. This final PSU is redundant and allows for hot swapping a PSU should one fail. Connecting the PSUs to different AC lines provides AC failover protection.

The system should continue to run and allow a hot swap of a defective PSU. Should there not be enough power to keep all of the leafs running, FabricIT EFM may power down some leafs. If this happens it will be necessary to reboot the chassis once the defective PSU has been replaced.

1. Check all FRUs for proper insertion and seating before connecting the AC power cords.
  - Boards
  - Power supplies
  - Leaf fan modules
  - Spine fan modules
2. Insert all leafs that you plan to use, in the chassis. Start at the bottom of the chassis and work your way up.
3. Insert the first two spines in the top two slots.
4. Insert the rest of the spines from the bottom of the chassis up to slot #3.
5. Insert thermal blanks in unused leaf slots to maintain balanced air flow.
6. Tighten all leaf and spine mounting screws.
7. Connect the power cords to the PSUs.
8. Connect the power cords to grounded electrical outlets.



With N+1 PSU redundancy do not power up the chassis with less than all PSUs installed.



A fully loaded IS5600 series switch system can draw 9.7 kW of power. Make sure that the outlets and circuits will not be overloaded. Spread out the load over at least two or three circuits, or a 3 phase supply.

## 4.1 Power Supply and Spine Board Indicator Status at Power ON



It can take up to 5 minutes to boot up the system. Turn off the system if any LEDs remain red for more than 5 minutes.

As the power is turned on, you should observe the following conditions for normal operation:


1. Power Supply Unit(s) AC OK and DC OK indicators are ON and FAIL indicators are OFF.
2. There is a *green* Status LED per spine board, per leaf board, and per management module that indicates power supplies are good.
3. Spine Board indicators will display status of internal links to the installed leaf boards. All PHY links to existing leaf Boards should be ON.
4. Check the Spine LEDs and make sure they coincide with Figure 68.

**Figure 68: Spine Side Panel Display Status Indications**



5. Check the Management Module LEDs and make sure they coincide with Figure 69.

**Figure 69: Management Module Status Indications for Normal Operation**





## 5 Switch Management Tools

This chapter describes the management module and tools available for Out-of-Band management of the switch system via FabricIT EFM.



There are 2 Ethernet ports (1 for each management module) that get connected to Ethernet switches. These switches must be configured to 10/100M auto-negotiation.

The IS5600 switch comes standard with a management software module for chassis management called FabricIT®. FabricIT is installed on all management modules for the managed switch systems based on InfiniScaleIV® technology. FabricIT includes a CLI, WebUI, SNMP, and chassis management features for software and IB management software (OpenSM).

You can get more information via the Mellanox FabricIT-EFM Software WebUI User's Manual or the Mellanox FabricIT-EFM Software User Manual.

The managed switch system includes the following software components:

- Embedded Subnet Manager (SM)
- Chassis manager and system BIST
- SNMP agent, 3rd party tool integration
- GUI
- Remote logging
- SSH/telnet
- Secured access in-band and out-band
- IPv4/IPv6 network stack

The chassis manager will give the user access to:

- Switch temperatures
- Power supply voltages
- Fan unit information
- Power unit information
- Flash memory
- Monitoring of:
  - AC power to the PSUs
  - DC power out from the PSUs
  - chassis failures
- querying for:
  - switch serial numbers
  - revisions
  - software version
  - SwitchX® FW version
  - switch temperatures

The manager also has the ability to burn new firmware and upgrade software on the switch.

## 5.1 InfiniBand Subnet Manager

The InfiniBand Subnet Manager (SM) is a centralized entity running in the switch. It discovers and configures all the InfiniBand fabric devices to enable traffic flow between those devices. The SM applies network traffic related configurations such as QoS, routing, partitioning to the fabric devices.

You can view and configure the Subnet Parameters (SM) via the CLI/WebUI.

Each InfiniBand subnet needs one subnet manager to discover, activate and manage the subnet. An InfiniBand® network requires a Subnet Manager to be running in either the Infiniband switch itself (switch based) or on one of the nodes which is connected to the Infiniband fabric (host based).

## 5.2 Accessing the CPU via the Ethernet Connector

Once the initial configuration is completed the management tools can be accessed through:

- SSH
- Telnet
- WEB
- SNMP
- XML

## 5.3 Upgrading Software

The new software and firmware updates are available to the user from the Mellanox Support website. Copy the update to a known location on a Remote server within your LAN.

Use the CLI or the GUI in order to perform the Software upgrade. For further information please refer to the FabricIT EFM user manual.



If FabricIT EFM is updated and the FW image in the leafs and spines of the chassis is an earlier version than the minimum that the new version of the software can work with, then the chassis management system may require up to ~45 minutes to update all of the FW images in all of the leafs and spines.



## 6 Troubleshooting

### 6.1 Power Supply Unit



If the Power supplies cannot supply enough power, the management module may shut down the some leafs.

As each PSU is plugged in, make sure that the green power LEDs on the PSU comes on.

**Issue 1. If the AC power LED is off:**

1. Check that the power cable is the correct power cable for your country.
2. Check that the power cable is plugged into a working outlet.
3. Check that the power cable has a voltage within the range of 100 - 240 volts AC.
4. Remove and reinstall the power cable.
5. Check the circuit breakers to be sure that the breaker has not tripped.
6. Check that the power cable is good. Replace the power cable.
7. If the AC power LED is green but the OK power LED is off or the FAIL LED is on – Replace the PSU.

### 6.2 Leaf Board

**Issue 2. The power LED for the Leaf board is off:**

1. Make sure that all of the PSUs are showing DC OK.
2. Uninstall and reinstall the Leaf board.
3. When the Yellow LED is on, this indicates a fault in the board, uninstall and reinstall the Leaf board.
4. If uninstalling and reinstalling the Leaf board does not work, burn the latest FW on the Leaf board and uninstall and reinstall the Leaf board.
5. Replace the Leaf board with a new one.



Should any of the boards shut down due to over temperature, wait 5 minutes and then follow the procedure starting with step 2

**Issue 3. The Physical link LED for the InfiniBand connector does not come on:**

1. Check that both ends of the cable are connected.
2. Check that the locks on the ends are secured.
3. Make sure that the latest FW version is installed on both the HCA card and the switch.
4. If media adapters are used check that the all connections are good, tight, and secure.
5. Replace the cable.

**Issue 4. The Activity indication does not come on:**

Check that the Subnet Manager has been started.

## 6.3 Management Module

### Issue 1. Yellow Status LED for the Chassis on the Management Module is Lit

1. Check the MLNX-OS management for confirmation and possible explanation of the alert.
2. Reset the master management module by pushing the rest button. If you have two management modules installed this will convert the master management module to the slave and convert the slave to the master.



If there is only one management module in the chassis all of the leafs and ports are reset by bringing them down and powering them up when the management module is removed.

3. Make sure the S.Fans and L.Fans LEDs are green.
4. Make sure that the spine and the leafs both have the same version of FW.
5. Reburn the FW and remove and reinstall the management module.
6. If you are running the chassis with only one management module, remove and reinstall the management module. Make sure the mating connectors of the unit are free of any dirt and/or obstacles. See Section 2.9.5 on page 57.
7. If you are running the chassis with only one management module, replace the management module.

### Issue 2. Yellow LED for the Leaf Fan on the Management Module is Lit

1. Check the MLNX-OS management for confirmation and possible explanation of the alert.
2. Make sure that there is nothing blocking the front or rear of the chassis and that the fan modules and ventilation holes are not blocked (especially dust over the holes).
3. If you find dust blocking the holes it is recommended to clean the fan unit and remove the dust from the front and rear panels of the switch using a vacuum cleaner.
4. Determine which fan module is problematic by checking the status LED on each fan module.
5. Remove and reinstall the problematic fan unit. Make sure the mating connector of the new unit is free of any dirt and/or obstacles. See Section 2.9.4 on page 54.
6. Replace the Leaf fan module.



There are two non-interchangeable types of leaf fan modules. If the new leaf fan does not go into the chassis confirm that it is the correct fan module.



Replace defective leaf fan modules as soon as they are identified.



Should any of the boards shut down due to over temperature, follow the procedure starting in step 2

**Issue 3. Yellow LED for the Spine Fan on the Management Module is Lit**

1. Check the MLNX-OS management for confirmation and possible explanation of the alert.
2. Determine which spine has a defective fan by checking the Fan LEDs on all of the spines.
3. Make sure that there is nothing blocking the front or rear of the chassis and that the fan modules and ventilation holes are not blocked (especially dust over the holes).
4. If you find dust blocking the holes it is recommended to clean the fan unit and remove the dust from the front and rear panels of the switch using a vacuum cleaner.
5. Remove and reinstall the fan unit of the spine. Make sure the mating connector of the new unit is free of any dirt and/or obstacles. See Section 2.9.4 on page 54.
6. Replace the spine fan module.



Replace defective spine fan modules as soon as they are identified.

## 6.4 Spine Board

**Issue 1. The yellow LED on the Spine board is lit:**

1. Check the MLNX-OS management for confirmation and possible explanation of the alert.
2. Make sure that there is nothing blocking the front or rear of the chassis and that the fan modules and ventilation holes are not blocked (especially dust over the holes).
3. If you find dust blocking the holes it is recommended to clean the fan unit and remove the dust from the front and rear panels of the switch using a vacuum cleaner.
4. Remove and reinstall the spine board. Make sure the mating connectors of the unit is free of any dirt and/or obstacles. See Section 2.9.3 on page 50.
5. Make sure that the spine and the Leafs both have the same version of FW.
6. Reburn the FW and remove and reinstall the spine.
7. Replace the spine board.

## 6.5 FabricIT Software

For more detailed instructions concerning MLNX-OS® software see the Mellanox MLNX-OS® SwitchX® Software WebUI User's Manual or the Mellanox MLNX-OS® SwitchX® Software User Manual.


## 7 Disassembly and Disposal

### 7.1 Disassembling the Chassis

1. Power down the chassis.
2. Remove all power cables.
3. Remove all connector cables.
4. Disconnect the ground lug from the ground post.
5. Loosen all locking screws for the leafs, spines, and management modules in the chassis.
6. Remove all leafs.
7. Remove all spines.
8. Remove all management modules.




Use enough people to safely lift this product.




This product and all of its parts are NOT to be disposed of with household waste. This product contains printed circuit boards cables and batteries. According to the WEEE Directive 2002/96/EC, all waste electrical and electronic equipment (EEE) should be collected separately and disposed of according to the directive.

9. Go to the Mellanox website for detailed instructions for disassembly of the FRUs and chassis according to the WEEE Directive.
10. Using a socket wrench, remove the hex head screws holding down the lock-down bar on the spine side of the chassis.

**Figure 70: Lock-down Bar**


11. Remove the lock-down bar.
12. Dispose of these pieces in a legal and environmentally friendly way.

**Figure 71: Face Plate Mounting Bolt Locations**

### 7.1.1 Removing the Chassis

1. Remove the screws connecting the upper brackets to the rack.
2. Remove the screws holding the chassis to the rack. These screws are located in the faceplate on the spine side of the chassis.
3. Remove the upper brackets from the chassis.
4. Remove the lock-down bars.



**Figure 72: Mechanical Lifting Device**

5. Put the container base (saved from the installation) on the fork lift.
6. Raise the container base to 1 cm below the level of the shelf.
7. Move the chassis away from the rack and onto the container base.
8. Put wedges around the chassis to prevent the chassis from rolling off of the container base.
9. Move the chassis away from the rack.
10. Dispose of the Chassis in a legal and environmental way.
11. Go to the Mellanox website for detailed instructions for disassembly of the chassis according to the WEEE Directive.

### 7.1.2 Removing the Bottom Shelf

1. Remove all of the bolts that are holding the shelf to the rack.
2. Remove the filler panels.
3. Remove the shelf.
4. Remove all of the caged nuts.

## 7.2 Disposal



According to the WEEE Directive 2002/96/EC, all waste electrical and electronic equipment (EEE) should be collected separately and not disposed of with regular household waste.

Dispose of this product and all of its parts in a responsible and environmentally friendly way.

Go to the Mellanox website for detailed instructions for disassembly according to the WEEE Directive.

## Appendix A: Specification Data

**Table 14 - IS5600 Switch Specification Sheet**

Physical		Power and Environmental	
H x W x D:	50.629" x 19" x 27" inches 1286mm x 482.6mm x 685mm The shelf adds 100mm to the height	Input Voltage:	100-240 VAC, 50-60Hz, 5 - 10A per inlet
Weight:	126.4kg (278.7 LBS) empty weight (no leafs, spines, or management modules) 328.6 kg (724.4 LBS) full configuration 126.4 kg (279 LBS) empty configuration	Temperature: Operating Non-operating	0 to 45 Celsius -40 to 70 Celsius
Mounting:	19" Rack mount (EIA-310)	Humidity (operating):	10% - 85% non-condensing
Max. Air Flow Through leafs:	16.59M3/min. (585.9 CFM)	Power Consumption Leaf:	Typical 82.28W (including QSFP passive power) Max. 89.74W (including QSFP passive power)
Max. Air Flow Through spines:	9.48 M3/min. (334.8 CFM)	Power Consumption Spine:	Typical 102.86W (including 2 fans) Max. 110.32W (including 2 fans)
SerDes Speeds:	20 and 40 Gb/s per port	Power Consumption Fan:	Typ 15.1W Max 135W
Connector Types:	QSFP	Power Consumption Management:	Typ 15W Max 22W
Center of Gravity CoGh :	637 (mm from bottom of chassis)	Power Consumption for optical cables QSFP:	2.0W power level #2
CoGw:	222 (mm from left side surface)	<b>IS5600</b>	648 ports
CoGd :	342.5(mm from port end surface) Measured from the bottom left corner as one faces the switch ports.	Power consumption: Typ	Passive: 5841W  Active: 6678W (including QSFP at 1W)  Optical: 7499W (including QSFP at 2W)
Max Heat Output:	30635.56 BTUs/hr	Max:	Optical: 9119W (including QSFP at 2W)

**Table 14 - IS5600 Switch Specification Sheet**

Protocol Support		Regulatory Compliance	
InfiniBand:	Auto-Negotiation of (20Gb/s, 40Gb/s)	Safety:	US/Canada: cTUVus EU: IEC60950 International: CB
QoS:	8 InfiniBand Virtual Lanes for all ports	EMC:	USA: FCC, Class A Canada: ICES, Class A EU: EN55022, Class A EU: EN55024, Class A EU: EN61000-3-2, Class A
Management:	Baseboard, Performance, and Device management Agents for full Infini-Band In-Band Management	ENVIRONMENTAL:	EU: EN61000-3-3, Class A Japan: VCCI, Class A
		ACOUSTIC:	EU: IEC 60068-2-64: Random Vibration
		SOUND POWER LEVEL:	EU: IEC 60068-2-29: Shocks, Type I / II EU: IEC 60068-2-32: Fall Test
			ISO 7779 ETS 300 753
			76.4 dB(A)
Scalability and Performance		Replaceable Parts	
Switching Performance:	Simultaneous wire-speed any port to any port	Leafs	Up to 36 leafs; 18-ports each
Addressing:	48K Unicast Addresses Max. per Subnet	Power Supplies	10 Power Supplies standard with 2 optional redundant power supplies available
	16K Multicast Addresses per Subnet	Leaf Fan Modules	8 Leaf Fan Modules
Switching Capacity:	52 Tb/s	Spine Fan Modules	18 Spine Fan Modules
		Spines	18
		Management Modules	2 available 1 required for operation

## A.1 EMI Certification

EMI certification on the fully populated chassis was performed with the chassis installed in a closed two-door rack using the chassis installation kit supplied by Mellanox Technologies.

## A.2 Approved Cables

For a list of all approved cables see:

[http://www.mellanox.com/related-docs/user\\_manuals/Mellanox\\_approved\\_cables.pdf](http://www.mellanox.com/related-docs/user_manuals/Mellanox_approved_cables.pdf)

## A.3 EMC Certifications

The list of approved certifications per chassis in different regions of the world is located on the Mellanox Website at:

[http://www.mellanox.com/related-docs/user\\_manuals/  
Regulatory\\_and\\_Compliance\\_Guide.pdf](http://www.mellanox.com/related-docs/user_manuals/Regulatory_and_Compliance_Guide.pdf)

EMC Statements are also in the Regulatory and Compliance Guide.

## Appendix B: Calculating the Weight of a Customized Chassis

The weight of a customized chassis can be calculated for any possible customization as follows.

Take the weight of a chassis with the following FRUs installed.

- All fans modules
- All power supplies

The weight of the IS5600 chassis configured above is 157.57kg.

To this add the weight of installed FRUs.

- Spines
- Leafs
- Leaf blanks
- Management modules

Fill in the table below to calculate the weight of your system.

Number of FRUs	FRU Type	Weight of 1 FRU	Total Weight / FRU Type
	Chassis as shipped		
	# of Spines *	3.77 =	
	# of leafs *	2.76 =	
	# of leaf blanks *	0.764 =	
	# of management modules *	3.15 =	
	Total	=	

This total is in kilograms. Multiply the total by 2.2 to get the total weight in pounds.

## Appendix C: Calculating the Power of a Chassis

To calculate the power consumption of a chassis add the power of the fans, spines, leafs, and management modules.

**Table 15 - Power Consumption of Chassis Parts**


Part	Typ Power Passive Cables	Typ. Power Optical Cables @ 2w Per Port
IB QDR leaf	82.28W	121.45W
Spine	102.86W	Not applicable
Fan	15.1W	Not applicable
Management module	15W	Not applicable


To calculate the chassis power at typical conditions fill in the table below.

Number of FRUs	FRU Type	Typ Power of 1 FRU	Total Power/FRU Type
	# of spines *	102.86W	
	# of leafs (passive cables)*	82.28W	
	# of leafs (optical cables)*	121.45W	
	# of management modules * for the PPC 460 manage- ment module	15W	
8	Chassis fan	15.1W	120.8W
	Total DC power		
	Total AC power: Total DC power / efficiency (85%)		

# Appendix D: Mechanical Drawing

Figure 73: Front Panel



**Figure 74: Rear Panel Leaf Side of the Switch**



Each Leaf has 18 QSFP connector ports. The switch can hold up to 36 leafs. Leaf Blanks must be in place when a slot is not populated with a Leaf. This is necessary to ensure proper air flow for cooling the leafs and spines.



## Appendix E: QSFP Interface

**Table 16 - InfiniBand QSFP Connector Pinout**

Connector Pin Number	Connector Pin Name	Signal Description
1	GND	Ground
2	Tx2n	Transmitter Inverted Data Input
3	Tx2p	Transmitter Non-Inverted Data Input
4	GND	Ground
5	Tx4n	Transmitter Inverted Data Input
6	Tx4p	Transmitter Non-Inverted Data Input
7	GND	Ground
8	ModSelL	Module Select
9	ResetL	Module Reset
10	Vcc Rx	+3.3 V Power supply receiver
11	SCL	2-wire serial interface clock
12	SDA	2-wire serial interface data
13	GND	Ground
14	Rx3p	Receiver Non-Inverted Data Output
15	Rx3n	Receiver Inverted Data Output
16	GND	Ground
17	Rx1p	Receiver Non-Inverted Data Output
18	Rx1n	Receiver Inverted Data Output
19	GND	Ground
20	GND	Ground
21	Rx2n	Receiver Inverted Data Output 3
22	Rx2p	Receiver Non-Inverted Data Output 3
23	GND	Ground
24	Rx4n	Receiver Inverted Data Output 3
25	Rx4p	Receiver Non-Inverted Data Output 3
26	GND	Ground
27	ModPrsL	Module Present
28	IntL	Interrupt
29	Vcc Tx	+3.3 V Power supply transmitter
30	Vcc 1	+3.3 V Power Supply
31	LPMODE	Low Power Mode
32	GND	Ground
33	Tx3p	Transmitter Non-Inverted Data Input
34	Tx3n	Transmitter Inverted Data Input
35	GND	Ground
36	Tx1p	Transmitter Non-Inverted Data Input
37	Tx1n	Transmitter Inverted Data Input
38	GND	Ground

**Figure 75: InfiniBand QSFP Connector Symbol**

**Figure 76: QSFP Connector Male and Female Views**


## Appendix F: Replacement Parts Ordering Numbers

**Table 17 - Replacement Parts Ordering Numbers**

Part Description	OPN
648 port QDR capable modular chassis, includes fans and power supplies, RoHS5	MIS5600Q-10DNC
Power supply unit PSU 1000W for Modular Switch Family	MTP005001
Power supply blank	MTM005001
Leaf board unit 18 port QDR	MIS5001QC
Modular Switch Family, Leaf - Blank	MTM005004
Spine board unit for QDR Switch system	MIS5002QC
Spine board blank	MTM005002
PPC460 Management Module	MIS5600MDC
Management module blank	MTM005003
Fan unit for chassis and leafs	MTF005002
Fan unit for Chassis Leaf side	MTF005001
Fan unit for Chassis Spine side	MTF005002
Modular Switch Family, Management - Blank	MTM005003
Rack Installation Kit for IS5600/SX6536 Series	MTR005600
Cable Management Device Set for IS5600/SX6536	MTR005601
Cables Set For IS5600/SX6536 Series	MTR005602
IS5600/SX6536, IS5300/SX6518 Series Modular Switch, leaf cooling chassis fan unit located on Leaf Side	MTF005001
IS5600/SX6536, IS5300/SX6518 Modular Switch, leaf cooling chassis fan unit located on Spine Side	MTF005002
MIS5X00, Modular Switch Series Spine Fan Unit	MTF005003
DB9 to RJ45 Harness	HAR000028
Power cord 250V 15A 2.0M C14 to C13	ACC000334
Power cord 125V 15A 2.0M C14 TO C13	ACC000242
Power cord Type B for USA, Canada, Mexico, Taiwan	ACC000204
Power cord Type H for Israel	ACC000205

**Table 17 - Replacement Parts Ordering Numbers (Continued)**

Part Description	OPN
Power cord Type E/F for Sweden, France, Germany, Netherlands, Russia	ACC000207
Power cord Type G for UK	ACC000208
Power cord Type D for India	ACC000209
Power cord Type I for China	ACC000210
Power cord Type J for Switzerland	ACC000211
Power cord Type B for Japan	ACC000212
Power cord Type I for Australia	ACC000213

# Appendix G: Installation Safety Warnings

## G.1 Installation Safety Warnings (English)

### 1. Installation Instructions



Read all installation instructions before connecting the equipment to the power source.

### 2. Bodily Injury Due to Weight



Use enough people to safely lift this product.

### 3. Heavy Equipment



This equipment is very heavy and should be moved using a mechanical lift to avoid injuries.

### 4. Installation in Restricted Access Location



This unit is intended for installation in a Restricted Access Location.

### 5. Risk of Electric Shock!



Risk of Electric Shock!

With the fan module removed power pins are accessible within the module cavity. DO NOT insert tools or body parts into the fan module cavity.

### 6. Over-temperature



This equipment should not be operated in an area with an ambient temperature exceeding the maximum recommended: 45°C (113°F). Moreover, to guarantee proper air flow, allow at least 8cm (3 inches) of clearance around the ventilation openings.

### 7. Stacking the Chassis



The chassis should not be stacked on any other equipment. If the chassis falls, it can cause bodily injury and equipment damage.

## 8. Redundant Power Supply Connection - Electrical Hazard



This product includes a redundant power or a blank in its place. In case of a blank power supply, do not operate the product with the blank cover removed or not securely fastened.

## 9. Double Pole/Neutral Fusing



This system has double pole/neutral fusing. Remove all power cords before opening the cover of this product or touching any internal parts.

## 10. Multiple Power Inlets



Risk of electric shock and energy hazard.

The PSUs are all independent.

Disconnect all power supplies to ensure a powered down state inside of the switch platform.

## 11. During Lightning - Electrical Hazard



During periods of lightning activity, do not work on the equipment or connect or disconnect cables.

## 12. Copper InfiniBand Cable Connecting/Disconnecting



Copper InfiniBand cables are heavy and not flexible, as such they should be carefully attached to or detached from the connectors. Refer to the cable manufacturer for special warnings/instructions.

## 13. Rack Mounting and Servicing



When this product is mounted or serviced in a rack, special precautions must be taken to ensure that the system remains stable. In general you should fill the rack with equipment starting from the bottom to the top.

## 14. Equipment Installation



This equipment should be installed, replaced, and/or serviced only by trained and qualified personnel.

## 15. Equipment Disposal



Disposal of this equipment should be in accordance to all national laws and regulations.

## 16. Local and National Electrical Codes



This equipment should be installed in compliance with local and national electrical codes.

## 17. Installation Codes



This device must be installed according to the latest version of the country national electrical codes. For North America, equipment must be installed in accordance to the applicable requirements in the US National Electrical Code and the Canadian Electrical Code.

## 18. Battery Replacement



**Warning:** Replace only with UL Recognized battery, certified for maximum abnormal charging current not less than 4mA

There is a risk of explosion should the battery be replaced with a battery of an incorrect type.

Dispose of used batteries according to the instructions.

## 19. UL Listed and CSA Certified Power Supply Cord



For North American power connection, select a power supply cord that is UL Listed and CSA Certified, 3 - conductor, [16 AWG], terminated with a molded plug rated at 125 V, [13 A], with a minimum length of 1.5m [six feet] but no longer than 4.5m.

For European connection, select a power supply cord that is internationally harmonized and marked “<HAR>”, 3 - conductor, minimum 1.0 mm<sup>2</sup> wire, rated at 300 V, with a PVC insulated jacket. The cord must have a molded plug rated at 250 V, 10 A.

## 20. High Leakage Current



**Warning:** High leakage current; Earth connection essential before connecting supply.

## 21. Add GND connection information



Before connecting this device to the power line, the protective earth terminal screws of this device must be connected to the protective earth in the building installation.

(GND Connection Information):

The building installation shall provide a means for a connection to protective earth; and the equipment shall be permanently connected to that by a service person.

A SERVICE PERSON shall check whether or not the socket - outlet from which the equipment is to be powered provides a connection to the building protective earth. If not, the SERVICE PERSON shall arrange for the installation of a PROTECTIVE EARTHING CONDUCTOR from the separate protective earthing terminal to the protective earth wire in the building. The equipment shall be installed in area where equipotential bonding exists ((such as a telecommunication centre or a dedicated computer room).

## 22. Installation codes



This device must be installed according to the latest version of the country national electrical codes. For North America, equipment must be installed in accordance to the applicable requirements in the US National Electrical Code and the Canadian Electrical Code.

## 23. Interconnection Of Units



Cables for connecting to the unit RS232 and Ethernet Interfaces must be UL certified type DP-1 or DP-2. (Note- when residing in non LPS circuit)

Overcurrent Protection: A readily accessible Listed branch circuit overcurrent protective device rated 20 A must be incorporated in the building wiring.

## 24. Hazardous Radiation Exposure



Caution – Use of controls or adjustment or performance of procedures other than those specified herein may result in hazardous radiation exposure.



CLASS 1 LASER PRODUCT and reference to the most recent laser standards IEC 60 825-1:1993 + A1:1997 + A2:2001 and EN 60825-1:1994+A1:1996+A2:2001

## 25. Proper Enclosure



A suitable electrical, mechanical and fire enclosure shall be provided by the end product manufacturer and or the end user.


## 26. Do Not Use the Switch as a Shelf or Work Space



Caution: Slide/rail mounted equipment is not to be used as a shelf or a work space. The rails are not intended for sliding the unit away from the rack. It is for permanent installation at final resting place only, not used for service and maintenance



## 27. WEEE Directive



According to the WEEE Directive 2002/96/EC, all waste electrical and electronic equipment (EEE) should be collected separately and not disposed of with regular household waste.

Dispose of this product and all of its parts in a responsible and environmentally friendly way.

## 5. Country of Norway Power Restrictions



This unit is intended for connection to a TN power system and an IT power system of Norway only.

## G.2 安裝安全性警告 (Chinese)

### 1. 安裝指示




本設備附有備援電源供應器或在適當位置配有空白蓋板。

### 2. 因重量導致的人身受傷



為了安全起見，請安排足夠的人員以合力抬起本產品。



### 3. 重設備



本設備極重，應使用機械式起重機來搬移，以避免人員受傷。

### 4. 安裝於進出管制區域



本設備設計安裝於進出管制區域。

## 5. 有觸電的危險



有觸電的危險！

拆除風扇模組後，即可接觸到模組空腔內的電源針腳。  
請勿將工具或機身零件插入到風扇模組空腔內。

## 6. 溫度過高



本設備不應在超過所建議的最高環境溫度的區域中運作：45°C (113°F)。此外，為了保證氣流的流通正常，請在通風口旁保留至少 8 公分 (3 英吋) 的間距。

## 7. 堆疊機箱



機箱不應堆疊在任何其他設備上。如果機箱掉落，可能造成人員受傷與設備損壞。

## 8. 複式電源連接時的電擊危險



本設備附有備援電源供應器或在適當位置配有空白蓋板。如果是電源供應器空白蓋板，在空白蓋板已取下或未牢牢固訂的情況下，請勿操作本產品。

## 9. 雙極 / 中性保險絲



本系統具有雙極 / 中性保險絲。請拔掉所有電源線後，再打開本產品的蓋板或碰觸任何內部零件。

## 10. 多電源輸入座



電擊與能源危害的危險。

所有 PSU 均各自獨立。

將所有電源供應器斷電，確保交換器平台內部在電源關閉狀態。

## 11. 閃電時的電擊危險



在閃電期間，不要使用本設備或連接或拔下纜線。

## 12. InfiniBand 銅纜連接 / 拔下



InfiniBand 銅纜很重且沒有彈性，因此必須小心裝在連接器上或自連接器上拔下。如需相關的特殊警告 / 指示，請洽詢纜線製造商。

## 13. 機架安裝與維修



此產品已安裝在機架中或在機架中維修時，必須採取特定預防措施以確保系統維持穩定。一般您應該將設備從底部到頂端放滿機架。

## 14. 設備安裝



本設備僅限由經過訓練與 / 或合格的人員安裝、更換或維修。

## 15. 設備棄置



棄置本設備應遵照所有國內法規。

## 16. 當地與國家電氣法規



請遵照當地與國家電氣法規安裝本設備。

## 17. 安裝法規



請務必遵循最新版的國家電氣法規，安裝本設備。在北美地區，請務必遵循美國國家電工法規和加拿大電工法規中的適用規定，安裝本設備。

## 18. 更換電池



警告：只能以 UL 認可電池，且取得最大異常充電電流低於 4mA 認證的電池進行更換。

若更換錯誤類型的電池，會有爆炸的危險。

請依據指示棄置廢電池。

## 19. UL 列名和 CSA 認證電源線



北美地區在接上電源時，請選用獲得 UL 列名和 CSA 認證、三個導體、[16 AWG] 附成型插頭，額定值為 125 V、[13 A]，長度至少 1.5 公尺 [六英尺]，但不超過 4.5 公尺的電源線。

歐洲地區在接上電源時，請選用國際協調式且標示有 <HAR> 字樣、三個導體、標稱截面至少 1.0 平方公厘，額定值為 300 V，採用 PVC 絕緣的電源線。電源線需有成型插頭，額定值為 250 V, 10 A。

## 20. 高漏電流

## 21. 新增 GND 連線資訊



須連接至大樓安裝中的保護地線。(GND 連線資訊)：

大樓安裝應提供連接保護地線的方式；設備一律只能由維修人員連接至地線。維修人員應檢查插座（供電給設備的插座）是否提供連接大樓保護地線的方式。如果沒有，維修人員應安排從獨立保護地線端子，將保護接地導體安裝至大樓的保護地線。設備應安裝於有等電位聯結的區域（例如，電信中心或專用電腦室）。

## 22. 安裝法規



請務必遵循最新版的國家電氣法規，安裝本設備。在北美地區，請務必遵循美國國家電工法規和加拿大電工法規中的適用規定，安裝本設備。

## 23. 互連設備



連接至 RS232 設備和乙太網路介面的纜線必須是 UL 認證類型 DP-1 或 DP-2。（請注意位於非 LPS 電路時）

過電流保護：準備好使用的列名分支電路過電流保護裝置最大額定值 20 A 必須整合在配線中。

## 24. 危險的放射線暴露



小心 – 使用非本手冊指定的控制、調整或執执行程序可能導致暴露在危險的放射線下。

配備光纜連接埠的產品



CLASS 1 雷射產品，並參照最新的雷射標準 IEC 60 825-1:1993 + A1:1997 + A2:2001 與 EN 60825-1:1994+A1:1996+ A2:2001


配備光纜連接埠的產品

## 25. 適當外殼




終端產品廠商或終端使用者應提供適合的電氣、機械和防火外殼。

## 26. 切換開關不可用作機架或工作空間



小心：滑軌 / 導軌安裝設備不可用作機架或工作空間。導軌不適用於將設備滑出機架使用。僅限永久安裝在最後安置區域時使用，不可用於維修和保養。

## 27. WEEE 指令




根據 WEEE 指令 2002/96/EC，所有廢棄的電氣與電子設備 (EEE)，應分開集中，而且不應與一般家庭廢棄物一起棄置。  
請以負責和環保的方式棄置本產品及其所有零件。

## 28. 挪威國家電源限制



本設備僅限連接至挪威的 TN 電源系統和 IT 電源系統。

在维修的时候一定要断开所有电源 (English translation "disconnect all power sources before service")



For altitude 2000 meter and below:

Warning for Class A:

种情况下,可能需要用户对其干扰采取切实可行的措施。


This is a Class A product. In a domestic environment this product may cause radio interference, in which case the user may be required to take adequate measures.

Veuillez lire la totalité des instructions d'installation avant de relier l'équipement au secteur.

## 2. Blessures à cause du poids



Prévoyez assez de personnel pour soulever ce produit en toute sécurité.



## 3. Équipement lourd



Cet équipement est très lourd et doit être déplacé avec un système de levage mécanique pour éviter les blessures.

## 4. Installation dans un emplacement à accès limité



Cette unité doit être installée dans un emplacement à accès limité.

## 5. Danger d'électrocution



Danger d'électrocution !

Lorsque le module de ventilation est retiré, les broches d'alimentation sont exposées dans l'emplacement du module.

NE PAS insérer d'outils ou la main dans l'emplacement du module.

## 6. Surchauffe



Cet équipement ne doit pas être en service dans un local dont la température dépasse le maximum recommandé de 45°C (113°F). En outre et pour garantir une circulation d'air correcte, laisser un espace d'au moins 8 cm (3") autour des orifices de ventilation.

## 7. Châssis empilé sur d'autres équipements



Le châssis ne doit pas être empilé sur d'autres équipements. S'il tombe, il peut endommager l'équipement ou entraîner des blessures.

## 8. Connexion de l'alimentation redondante : danger d'électrocution



Ce produit est équipé d'une alimentation redondante ou d'un cache si elle est absente. Dans ce dernier cas, ne pas faire fonctionner le produit si le cache est retiré ou mal fixé.

## 9. Fusibles phase/neutre



Ce système dispose de fusibles phase/neutre. Débranchez tous les cordons d'alimentation avant d'ouvrir le capot ou de toucher tout élément à l'intérieur.

## 10. Plusieurs prises d'alimentation



Risque et danger d'électrocution.

Les alimentations sont toutes indépendantes.

Pour s'assurer que le commutateur est bien hors tension, débranchez toutes les alimentations.

## 11. En cas d'orage, danger d'électrocution



Pendant un orage, ne pas travailler sur l'équipement ni brancher ou débrancher des câbles.

## 12. Connexion et déconnexion du câble InfiniBand en cuivre



Les câbles InfiniBand en cuivre sont lourds et peu flexibles. Par conséquent, il faut procéder avec soin pour les brancher ou les débrancher des connecteurs. Consulter le fabricant du câble pour obtenir des instructions ou des avertissements spécifiques.

## 13. Montage en rack et maintenance



Lors du montage ou de la maintenance de ce produit dans un rack, il faut faire spécialement attention pour s'assurer que l'ensemble reste stable. En règle générale, le rack doit être rempli en commençant par le bas.

## 14. Installation de l'équipement



Cet équipement ne doit être installé, remplacé et maintenu que par un personnel formé et qualifié.

## 15. Mise au rebut de l'équipement



La mise au rebut de cet équipement doit se faire conformément à toutes les lois et réglementations nationales.



## 16. Codes électriques locaux et nationaux



Cet équipement doit être installé conformément aux codes électriques locaux et nationaux.

## 17. Codes d'installation



Cet appareil doit être installé conformément à la version la plus récente des codes électrique nationaux. En Amérique du Nord, l'équipement doit être installé en respectant les exigences de l'US National Electrical Code et du Code canadien de l'électricité.

## 18. Remplacement de la batterie



**Avertissement :** ne remplacer qu'avec une batterie UL, certifiée pour accepter un courant de charge anormal maximal supérieur ou égal à 4 mA.

Si la batterie n'est pas remplacée par un type correct, il y a un risque d'explosion. Les batteries usagées doivent être mises au rebut conformément aux instructions.

## 19. Cordon d'alimentation UL Listed et certifié CSA



Pour le branchement électrique en Amérique du Nord, utiliser un cordon d'alimentation UL Listed et CSA Certified, à 3 conducteurs [calibre 16 AWG], avec une prise moulée 125 V [13 A], faisant au moins 1,5 m de long [six pieds] et au plus 4,5 m.

Pour le branchement électrique en Europe, utiliser un cordon d'alimentation au format international harmonisé (marqué <HAR>), à 3 conducteurs d'au moins 1 mm<sup>2</sup> de section, 300 V, avec une gaine isolante en PVC. Le cordon doit avoir une prise moulée 250 V 10 A.

## 20. Courant de fuite élevé



**Avertissement :** courant de fuite élevé, une connexion à la terre est indispensable avant de brancher l'alimentation.

## 21. Information d'ajout de branchement à la terre (GND)



Avant de relier cet appareil au secteur, ses vis des bornes de la terre de protection doivent être reliées à la terre de l'installation électrique de l'immeuble. (Informations de branchement à la terre) :

L'installation électrique doit fournir une connexion à la terre, et un technicien de maintenance doit y relier l'équipement de façon permanente.

UN TECHNICIEN DE MAINTENANCE doit vérifier si la prise à laquelle sera branché l'équipement fournit une connexion à la terre. Si ce n'est pas le cas, le TECHNICIEN DE MAINTENANCE doit arranger l'installation d'un CONDUCTEUR DE MISE A LA TERRE, allant de la borne de mise à la terre jusqu'au conducteur de terre de l'immeuble. Cet équipement doit être installé dans une zone disposant de liaisons équipotentielles (comme un centre de télécommunications ou une salle informatique dédiée).

## 22. Codes d'installation



Cet appareil doit être installé conformément à la version la plus récente des codes électrique nationaux. En Amérique du Nord, l'équipement doit être installé en respectant les exigences de l'US National Electrical Code et du Code canadien de l'électricité.

## 23. Interconnexion des unités



Les câbles de connexion aux interfaces RS232 et Ethernet de l'appareil doivent être certifié UL de type DP-1 ou DP-2. (Note : en cas d'installation sur un circuit dont la puissance n'est pas limitée)

Protection contre les surintensités : le câblage de l'immeuble doit intégrer un dispositif certifié de protection contre les surintensités, calibré à 20 A et aisément accessible.

## 24. Exposition à des rayonnements dangereux



Attention : l'utilisation de commandes, l'ajustement ou la conduite de procédures autres que celles indiquées ici pourraient conduire à une exposition dangereuse à des rayonnements.

Pour les produits disposant de ports optiques



PRODUIT LASER DE CLASSE 1 et référence aux plus récentes normes relatives aux lasers : IEC 60 825-1:1993 + A1:1997 + A2:2001 et EN 60825-1:1994+A1:1996+A2:2001


Pour les produits disposant de ports optiques

## 25. Armoire de protection appropriée




Une enceinte appropriée aux niveaux électrique, mécanique et incendie doit être fournie par le constructeur du produit fini ou par l'utilisateur.

## 26. Ne pas utiliser comme étagère ou plan de travail



Attention : un équipement coulissant ou monté sur rail ne doit pas servir d'étagère ni de plan de travail. Les rails ne sont pas destinés à faire coulisser l'unité hors du rack. Ils sont destinés à une installation permanente à l'emplacement final, pas pour l'entretien ni la maintenance.

## 27. Directive DEEE



Selon la Directive 2002/96/CE (DEEE), tous les déchets d'équipements électriques et électroniques (EEE) doivent être collectés séparément et ne pas être mis au rebut avec les déchets ménagers habituels.

Ce produit et toutes ses pièces doivent être mis au rebut d'une manière responsable, respectant l'environnement.

## 28. Restrictions concernant l'alimentation pour la Norvège

## G.4 Installation Sicherheitshinweise(German)

### 1. Installationsanleitungen




Lesen Sie alle Installationsanleitungen, bevor Sie das Gerät an die Stromversorgung anschließen.

### 2. Verletzungsgefahr wegen des Gewichts



Um das Produkt sicher anzuheben, genügend Personen einsetzen.



### 3. Schweres Gerät



Dieses Gerät ist sehr schwer und muss mit einem mechanischen Hebegerät verschoben werden, um Verletzungen zu vermeiden.

### 4. Installation an Bereich mit eingeschränktem Zugang



Diese Gerät ist für die Installation in einem Bereich mit beschränktem Zugang vorgesehen.

### 5. Stromschlagrisiko



Stromschlagrisiko!

Bei abgenommenem Ventilatormodul sind die Stromkontakte in der Modulvertiefung zugänglich.

Es dürfen KEINE Werkzeuge oder Körperteile in die Vertiefung des Ventilatormoduls gelangen.

### 6. Übertemperatur



Dieses Gerät sollte nicht in einem Bereich mit einer Umgebungstemperatur über der maximal empfohlenen Temperatur von 45°C (113°F) betrieben werden. Es ist ein Luftstrom von 200 LFM bei maximaler Umgebungstemperatur erforderlich. Außerdem sollten mindestens 8 cm (3 in.) Freiraum um die Belüftungsöffnungen sein, um einen einwandfreien Luftstrom zu gewährleisten.

## 7. Stapeln des Chassis



Das Chassis sollte nicht auf andere Geräte gestapelt werden. Wenn das Chassis herunterfällt, kann es zu Verletzungen und Beschädigungen an Geräten führen.

## 6. Zweipolig/Neutrale Sicherung



Achtung:

Zweipolige bzw. Neutraleiter-Sicherung im Netzteil. Netzstecker ziehen, um sicherzustellen, daß keine Spannung am Gerät anliegt. Entfernen Sie alle Netzkabel vor dem Öffnen der Abdeckung dieses Produkts oder dem Berühren der Innenteile.

## 8. Mehrere Stromeingänge



Risiko eines Stromschlags und Stomgefahr.

Alle Stromversorgungseinheiten sind unabhängig.

Trennen Sie alle Stromversorgungen, um einen abgeschalteten Zustand im Inneren der Switch-Plattform sicherzustellen.

## 9. Bei Gewitter - Elektrische Gefahr



Arbeiten Sie während eines Gewitters und Blitzschlag nicht am Gerät, schließen Sie keine Kabel an oder ab.

## 10. Anschließen/Trennen von InfiniBand-Kupferkabel



InfiniBand-Kupferkabel sind schwer und nicht flexible. Deshalb müssen sie vorsichtig an die Anschlüsse angebracht bzw. davon getrennt werden. Lesen Sie die speziellen Warnungen und Anleitungen des Kabelherstellers.

## 11. Rack-Montage und Wartung



Wenn dieses Produkt in einem Rack montiert oder gewartet wird, sind besondere Vorsichtsmaßnahmen zu ergreifen, um die Stabilität des Systems zu gewährleisten. Im Allgemeinen sollten Sie das Gestell von unten nach oben mit Geräten füllen.

## 12. Geräteinstallation



Diese Gerät sollte nur von geschultem und qualifiziertem Personal installiert, ausgetauscht oder gewartet werden.

### 13. Geräteentsorgung



Die Entsorgung dieses Geräts sollte unter Beachtung aller nationalen Gesetze Bestimmungen erfolgen.

### 14. Regionale und nationale elektrische Bestimmungen



Dieses Gerät sollte unter Beachtung der regionalen und nationalen elektrischen Bestimmungen installiert werden.

### 15. Installationscodes



Dieses Gerät muss entsprechend der aktuellsten Version des National Electrical Code installiert werden. In Nordamerika muss das Gerät gemäß den geltenden Anforderungen des US National Electrical Code und des Canadian Electrical Code installiert werden.

### 16. Akkuaustausch



Warnung: Nur durch von UL anerkannten Akkus ersetzen, die für maximalen anormalen Ladestrom von nicht weniger als 4mA zertifiziert sind.  
Es besteht Explosionsgefahr, wenn der Akku durch einen Akku eines falschen Typs ersetzt wird.  
Akkus gemäß den Anweisungen entsorgen.

### 17. UL- und CSA-zertifiziertes Netzkabel



Für Nordamerika Stromanschluss, wählen Sie ein Netzkabel, das UL-und CSA Zertifiziert  
3 - Leiter, [18 AWG], mit einem angespritztem Stecker bewertet bei 125 V, [15], mit einer Mindestlänge von 1,5 m [Six Feet] aber nicht mehr als 4,5 m.  
Für die europäischen Zusammenhang, wählen Sie ein Netzkabel, das international harmonisiert und der Aufschrift "<HAR>",  
3 - Leiter, mindestens 0,75 mm<sup>2</sup> Draht, bewertet mit 300 V, mit einem PVC-Mantel isoliert. Das Kabel muss eine angespritztem Stecker bewertet bei 250 V, 10 A. "

### 18. Hoher Ableitstrom



WARNUNG: Hohe Ableitstrom; Earth Verbindung, bevor Sie die Verbindung von wesentlicher Bedeutung werden.

### 19. Informationen zum Erdungsanschluss



Bevor Sie dieses Gerät an das Stromnetz, die Schutz Erde Terminal Schrauben dieses Gerät muss an den Schutzleiter in der Gebäudeinstallation.

## 20. Installationscodes



Dieses Gerät muss installiert sein, entsprechend auf die neueste Version des Landes National Electrical Code. Für Nordamerika, müssen in Übereinstimmung mit den geltenden Vorschriften in der US-amerikanischen National Electrical Code und dem Canadian Electrical Code.

## 21. Verbindung der Geräte untereinander



Kabel für den Anschluss an das Gerät RS232- und Ethernet-Schnittstellen müssen UL zertifiziert Typ DP-1 oder DP-2. (Hinweis-, wenn nicht mit Wohnsitz in LPS-Schaltung)

Überstromschutz: Eine leicht zugängliche Auflistung Abzweigleitung Überstrom-Schutzeinrichtung 20 A bewertet werden müssen in dem Gebäude Verkabelung.

## 22. Gefährliche Strahlung



Achtung – Nutzung von Steuerungen oder Einstellungen oder Ausführung von Prozeduren, die hier nicht spezifiziert sind, kann zu gefährlichem Strahlenkontakt führen..



Klasse 1 Laserprodukt und Referenzen zu den aktuellsten Lasterstandards :  
ICE 60 825-1:1993 + A1:1997 + A2:2001 und EN 60825-1:1994+A1:1996+ A2:2001

## 23. Geeignetes Gehäuse



Geeigneter elektrischer, mechanischer und Feuerschutz sind vom Hersteller des Endprodukts oder dem Endbenutzer bereitzustellen.

## 24. Switch nicht als Regal oder Arbeitsplatz nutzen



Achtung: Auf Schieber/Schienen montiertes Gerät ist nicht als Regal oder Arbeitsbereich zu nutzen. Die Schienen sind nicht dafür bestimmt, die Einheit aus dem Gestell weg zu ziehen. Sie sind nur für die permanente Installation an einem endgültigen Standort gedacht, nicht für Instandhaltung und Wartung.

## 25. WEEE-Direktive



Gemäß WEEE Directive 2002/96/EC müssen alle elektrischen und elektronischen Abfallgeräte (EEE) separat gesammelt und nicht mit normalem Haushaltsmüll entsorgt werden.

Dieses Produkt und alle seine Teile in verantwortungsvoller und umweltfreundlicher Art und Weise entsorgen.

## G.5 Advertencias de seguridad de instalación (Spanish)

### 1. Instrucciones de instalación




Antes de conectar el equipo a la fuente de alimentación, leer todas las instrucciones de instalación.

### 2. Lesión corporal a causa de peso



Recurra a suficientes personas para levantar este producto sin



### 3. Equipos pesados



Dado que el equipo es muy pesado, se debe mover únicamente mediante un elevador mecánico, para evitar lesiones.

### 4. Instalación en lugares con acceso restringido



Esta unidad ha sido ideada para instalar en lugares de acceso restringido.

### 5. Riesgo de descarga eléctrica



¡Riesgo de descarga eléctrica!

Con el módulo del ventilador quitado, se obtiene acceso a las clavijas de alimentación desde dentro de la cavidad del módulo.

NO introducir herramientas ni partes del cuerpo en la cavidad del módulo del ventilador.

### 6. Sobretemperatura



No se debe utilizar el equipo en un área con una temperatura ambiente superior a la máxima recomendada: 45°C. Además, para garantizar una circulación de aire adecuada, se debe dejar como mínimo un espacio de 8 cm (3 pulgadas) alrededor de las aberturas de ventilación.

## 7. Apilamiento del chasis



Los chasis no se deben apilar sobre otros equipos. La caída del chasis podría causar lesiones corporales, así como daños al equipo.

## 8. Conexión redundante de fuente de alimentación: peligro de descarga



Este producto incluye una fuente de alimentación redundante o, en su lugar, una vacía. Si se dispone de una fuente de alimentación vacía, no utilizar el producto si su tapa está quitada o no está bien cerrada.

## 9. Fusible neutro o de polo doble



Dos fusibles, uno en el polo y otro en el neutro. Quitar los cables de corriente antes de abrir la tapa de este producto o tocar cualquier componente interno.

## 10. Tomas de alimentación múltiples



Riesgo de descarga eléctrica y peligro de corriente.  
Todas las fuentes de alimentación son independientes.  
Desconecte todas las fuentes de alimentación, para asegurar que no haya corriente alguna dentro de la plataforma de conmutación.

## 11. Al haber rayos: peligro de descarga



No utilizar el equipo ni conectar o desconectar cables durante períodos de actividad de rayos.

## 12. Cable de conexión y desconexión InfiniBand de cobre



Dado que los cables de cobre InfiniBand son pesados y no son flexibles, su conexión a los conectores y su desconexión se deben efectuar con mucho cuidado. Para ver advertencias o instrucciones especiales, consultar al fabricante del cable.

## 13. Montaje y mantenimiento del bastidor



Al instalar o realizar el mantenimiento de este aparato en un bastidor, es preciso adoptar precauciones especiales para garantizar que el sistema se mantenga estable. En general, en un bastidor, los equipos se deben instalar comenzando desde abajo hacia arriba.



#### 14. Instalación del equipo



La instalación, el reemplazo y el mantenimiento de este equipo estarán a cargo únicamente de personal capacitado y competente.

#### 15. Eliminación del equipo



La eliminación definitiva de este equipo se debe efectuar conforme a todas las leyes y reglamentaciones nacionales.

#### 16. Códigos eléctricos locales y nacionales



Este equipo se debe instalar conforme a los códigos eléctricos locales y nacionales.

#### 17. Códigos de instalación



Este dispositivo se debe instalar conforme a la versión más reciente de los códigos eléctricos nacionales del país en cuestión. En América del Norte, el equipo se debe instalar de acuerdo con las disposiciones vigentes del Código Eléctrico Nacional de los EE.UU. y del Código Eléctrico de Canadá.

#### 18. Cambio de batería



Il y a danger d'explosion s'il y a remplacement incorrect de la batterie. Remplacer uniquement avec une batterie du même type ou d'un type équivalent recommandé par le constructeur.

Mettre au rebut les batteries usagées conformément aux instructions du fabricant.

#### 19. Cable de alimentación homologado por UL y con certificación CSA



En conexiones de América del Norte, seleccionar un cable de alimentación homologado por UL y con certificación CSA de tres conductores, [16 AWG], terminado en un enchufe moldeado con capuchón de 125 voltios nominal, [13 A], con una longitud mínima de 1,5 metros, pero no más de 4,5 metros.

En conexiones europeas, seleccionar un cable de alimentación armonizado internacionalmente y marcado "<HAR>", de tres conductores, hilo de 1,0 mm<sup>2</sup> como mínimo, 300 voltios nominal, con cobertura protectora aislante de PVC. El cable debe tener un enchufe moldeado con capuchón de 250 voltios nominal, 10 A.

#### 20. Alta corriente de fuga



ADVERTENCIA: Alta corriente de fuga. Es esencial efectuar la conexión a tierra antes de conectar la alimentación.

## 21. Agregar información de conexión a tierra (GND)



Antes de conectar el dispositivo a la línea de alimentación, los tornillos del terminal de la puesta a tierra de protección del dispositivo se deben conectar a la puesta a tierra de protección de la instalación del edificio.

(Información de conexión a tierra):

La instalación del edificio deberá proveer un medio para la conexión con la puesta a tierra de protección y un técnico de servicio deberá conectar permanentemente el equipo a dicho medio de conexión.

Un TÉCNICO DE SERVICIO comprobará si la toma eléctrica de la que se suministrará corriente al equipo provee una conexión con la puesta a tierra de protección del edificio. De no ser así, el TÉCNICO DE SERVICIO se encargará de instalar un CONDUCTOR DE CONEXIÓN A TIERRA DE PROTECCIÓN, del terminal de puesta a tierra de protección separado al conductor de tierra de protección del edificio. El equipo se instalará en un área donde haya conexión equipotencial, como por ejemplo, un centro de telecomunicaciones o una sala de computadoras dedicada.

## 22. Códigos de instalación



Este dispositivo se debe instalar conforme a la versión más reciente de los códigos eléctricos nacionales del país en cuestión. En América del Norte, el equipo se debe instalar de acuerdo con las disposiciones vigentes del Código Eléctrico Nacional de los EE.UU. y del Código Eléctrico de Canadá.

## 23. Interconexión de unidades



Los cables para la conexión con las interfaces RS232 y Ethernet de la unidad deben estar homologados por UL tipo DP-1 o DP-2. (Nota: cuando residen en circuito no de tipo LPS)

Protección contra sobrecargas: Al cableado del edificio se debe incorporar un dispositivo de protección contra sobrecargas de circuito derivado, de fácil acceso, con una corriente nominal de 20 A.

## 24. Exposición a radiación peligrosa



Precaución: el uso de controles o ajustes o la realización de procedimientos distintos de los que aquí se especifican podrían causar exposición a niveles de radiación peligrosos.



PRODUCTO LÁSER DE CLASE 1 y referencia a las normas de láser más recientes: IEC 60825-1:2007/03 y EN 60825-1:2007

## 25. Recinto adecuado



El fabricante del producto final o el usuario final deberán suministrar un confinamiento adecuado para componentes eléctricos y mecánicos y contra incendio.

## 26. No utilizar el conmutador como estante ni como espacio de trabajo



Cuidado: Equipos montados en deslizadores o rieles no se deben utilizar como estantes ni como espacio de trabajo. La finalidad de los rieles no es deslizar la unidad hacia afuera del bastidor. Sirven solo para la instalación permanente en el lugar de destino final, no para fines de servicio o mantenimiento

## 27. Directiva WEEE



Conforme a la Directiva 2002/96/CE sobre RAEE, todos los residuos de equipos eléctricos y electrónicos (EEE) se deben recolectar por separado y no se deben eliminar junto con residuos domésticos.

Al deshacerse de este producto y de todas sus partes, hágalo de una manera responsable y respetuosa con el medio ambiente.

## G.6 Предупреждения по технике безопасности при установке (Russian)

### 1. Инструкция по установке




Перед подключением оборудования к источнику питания следует ознакомиться с инструкцией по установке.

### 2. Травмы при переносе тяжелых предметов



Для поднятия этого изделия следует задействовать достаточное количество людей.



### 3. Тяжелое оборудование



Это очень тяжелое оборудование, поэтому его следует перемещать с помощью механического подъемника во избежание травм.

#### 4. Опасность поражения электрическим током



Это устройство предназначено для установки в помещении с ограниченным доступом.

#### 5. Опасность поражения электрическим током



Опасность поражения электрическим током!

Когда снят вентиляторный модуль, существует возможность повреждения контактов питания в его углублении.

НЕ вставлять инструменты или части тела в углубление вентиляторного модуля.

#### 6. Перегрев



Не эксплуатировать это оборудование в помещении с температурой окружающей среды, превышающей максимально рекомендуемое значение: 45 °C (113 °F). Более того, для надлежащей вентиляции следует обеспечить зазор вокруг вентиляционных отверстий не менее 8 см (3 дюйма).

#### 7. Установка шасси поверх другого оборудования



Не устанавливать шасси поверх другого оборудования. Падение шасси может привести к травмам и повреждению оборудования.

#### 8. Опасность поражения электрическим током резервного источника питания



В этом изделии установлен резервный источник питания или модуль-заглушка. Если установлен модуль-заглушка, не эксплуатировать изделие со снятой или ненадежно закрепленной крышкой модуля-заглушки.

#### 9. Двухполюсный предохранитель на фазном и нейтральном проводах



В этой системе установлен двухполюсный предохранитель на фазном и нейтральном проводах. Открывать кожух этого изделия или касаться внутренних деталей можно только после отсоединения всех шнуров питания.

#### 10. Несколько источников питания



Опасность поражения электрическим током и опасные энергетические воздействия.

Блоки питания независимы друг от друга.

Чтобы обесточить все компоненты внутри платформы коммутации, следует отсоединить все блоки питания.

## 11. Опасность поражения электрическим током во время грозы



Во время грозы запрещается использовать оборудование и подключать или отключать кабели.

## 12. Подсоединение и отсоединение медных кабелей InfiniBand



Медные кабели InfiniBand тяжелые и негибкие, поэтому следует осторожно их подсоединять и отсоединять. За особыми предупреждениями и указаниями следует обратиться к производителю кабеля.

## 13. Установка или обслуживание в стойке



При установке или обслуживании этого изделия в стойке следует обеспечить устойчивость системы. Как правило, стойка заполняется оборудованием снизу вверх.

## 14. Установка оборудования



Устанавливать, заменять и/или обслуживать это оборудование должен только подготовленный и квалифицированный персонал.

## 15. Утилизация оборудования



Это оборудование утилизируется в соответствии с национальными законами и постановлениями.

## 16. Местные и национальные правила установки электрооборудования



Это оборудование устанавливается в соответствии с местными и национальными правилами установки электрооборудования.

## 17. Правила установки электрооборудования



Это устройство устанавливается в соответствии с последним изданием национальных правил установки электрооборудования. В Северной Америке оборудование устанавливается в соответствии с действующими требованиями Национальных правил эксплуатации и обслуживания электрических установок США и Канады.

## 18. Замена аккумулятора



Осторожно! Заменять только аккумулятором, одобренным организацией UL и рассчитанным на максимальный аномальный зарядный ток не менее 4 мА. Существует риск взрыва при замене аккумулятора другим аккумулятором неправильного типа. Отработавшие аккумуляторы утилизируются в соответствии с указаниями.

## 19. Шнур питания, включенный в номенклатуру UL и сертифицированный Канадской ассоциацией стандартизации (CSA)



Подключение к электропитанию в Северной Америке выполняется с помощью шнура питания, включенного в номенклатуру UL и сертифицированного Канадской ассоциацией стандартизации (CSA), 3-жильного, [16 AWG], длиной от 1,5 м [6 футов] до 4,5 м, с литой вилкой, рассчитанной на 125 В [13 А].

Подключение к электропитанию в Европе выполняется с помощью гармонизированного шнура питания с маркировкой <HAR>, 3-жильного, с сечением жилы не менее 1,0 мм<sup>2</sup>, рассчитанного на номинальное напряжение 300 В, с ПВХ оболочкой. Шнур должен иметь литую вилку, рассчитанную на 250 В, 10 А.

## 20. Высокий ток утечки



Осторожно! Высокий ток утечки. Заземлить перед подключением к электропитанию.

## 21. Добавить информацию о подключении к заземлению



Перед подключением этого устройства к сети электропитания следует подсоединить винты заземляющего зажима устройства к защитному заземлению здания. (Информация о подключении к заземлению):

В здании должна быть предусмотрена возможность подключения к защитному заземлению, к которому техник должен стационарно подключить оборудование.

ТЕХНИК должен убедиться, что розетка, от которой будет питаться оборудование, подключена к защитному заземлению здания. Если розетка не подключена к защитному заземлению, ТЕХНИК должен организовать прокладку ПРОВОДА ЗАЩИТНОГО ЗАЗЕМЛЕНИЯ от отдельного зажима защитного заземления до провода защитного заземления в здании. Оборудование устанавливается в помещении с уравниванием потенциалов (например, в телекоммуникационном центре или специальном помещении для компьютеров).

## 22. Правила установки электрооборудования



Это устройство устанавливается в соответствии с последним изданием национальных правил установки электрооборудования. В Северной Америке оборудование устанавливается в соответствии с действующими требованиями Национальных правил эксплуатации и обслуживания электрических установок США и Канады.

## 23. Подсоединение устройств



Для подключения к разъемам RS232 и Ethernet используются кабели типа DP-1 или DP-2, сертифицированные организацией UL. (Примечание. При подключении к сети без ограниченного источника электропитания) Максимальная токовая защита. В проводку здания в легкодоступном месте следует включить устройство защиты от перегрузки по току номиналом 20 А.

## 24. Опасное радиационное воздействие



Внимание! Выполнение не изложенных здесь регулировок, настроек и процедур может вызвать опасное радиационное воздействие.

ЛАЗЕРНОЕ ИЗДЕЛИЕ КЛАССА 1 и ссылка на последние стандарты по безопасности лазерных изделий IEC 60 825-1:1993 + A1:1997 + A2:2001 и EN 60825-1:1994 + A1:1996 + A2:2001.

## 25. Соответствующий кожух




Производитель конечного изделия и/или конечный пользователь должны обеспечить соответствующий электрический, механический и противопожарный кожух.

## 26. Не использовать коммутатор как полку или рабочую



Внимание! Оборудование, установленное на направляющих, не должно использоваться как полка или рабочая поверхность. Направляющие не предназначены для удерживания устройства, выдвинутого из стойки. Они предназначены для стационарной установки только в конечном положении и не используются для обслуживания устройства.

## 27. Директива WEEE



В соответствии с Директивой 2002/96/EC (WEEE) отходы электрического и электронного оборудования должны собираться и утилизироваться отдельно от обычных бытовых отходов.

Следует утилизировать это изделие и все его части ответственным и экологически безопасным способом.

## G.7 Avertismente privind siguranța la instalare (Romanian)

### 1. Instrucțiuni de instalare




Citiți toate instrucțiunile de instalare înainte de a conecta

## 2. Accidentare cauzată de greutate



Apelați la un număr suficient de persoane pentru a ridica în siguranță acest produs.



## 3. Echipament greu



Acest echipament este foarte greu și trebuie să fie mutat folosind un dispozitiv mecanic de ridicare pentru a evita producerea de leziuni.

## 4. Instalarea într-un loc cu acces limitat



Această unitate este destinată instalării într-un loc cu acces limitat.

## 5. Risc de șoc electric



Risc de șoc electric!

Odată ce modulul ventilator este îndepărtat, pinii electrici sunt accesibili în cavitatea modulului.

NU introduceți instrumente sau părți din corp în cavitatea modulului ventilator.

## 6. Temperatură în exces



Acest echipament nu trebuie să fie acționat într-o zonă unde temperatura ambiantă depășește valoarea maximă recomandată: 45°C (113°F). În plus, pentru a asigura un flux de aer adecvat, lăsați un spațiu liber de cel puțin 8 cm (3 inch) în jurul fantelor de ventilare.

## 7. Suprapunerea cadrului



Cadrul nu trebuie să fie suprapus peste niciun alt echipament. În cazul în care cadrul cade, poate cauza leziuni corporale și deteriorări ale echipamentului.

## 8. Conexiunea la o sursă de alimentare electrică suplimentară - pericol electric



Acest produs include o sursă de alimentare suplimentară sau un spațiu gol în locul acesteia. În cazul în care spațiul pentru sursa de alimentare este gol, nu operați produsul când capacul orb este îndepărtat sau nu este fixat în mod sigur.



## 9. Siguranță fuzibilă bipolară/neutră



Acest sistem este prevăzut cu siguranță fuzibilă bipolară/neutră. Îndepărtați toate cordoanele de alimentare înainte de a deschide capacul acestui produs sau înainte de a atinge orice componente interne.

## 10. Multiple mufe electrice



Risc de șoc electric și pericol electric.

Toate aparatele cu alimentare de la rețea sunt independente.

Deconectați toate sursele de alimentare cu energie pentru a asigura decuplarea în interiorul platformei de comutare.

## 11. În timpul descărcărilor electrice - pericol electric



În timpul perioadelor cu descărcări electrice luminoase, nu lucrați cu echipamentul sau nu conectați sau deconectați cablurile.

## 12. Conectarea/deconectarea cablului din cupru InfiniBand



Cablurile InfiniBand din cupru sunt grele și inflexibile, de aceea trebuie să fie atașate sau detașate de conectori cu grijă. Consultați producătorul de cabluri pentru avertismente/instrucțiuni speciale.

## 13. Montarea sau depanarea într-un rack



Când acest produs este montat sau depanat într-un rack, trebuie să fie luate măsuri de precauție speciale pentru a se asigura că sistemul rămâne stabil. În general, trebuie să umpleți rack-ul cu echipamente începând de jos în sus.

## 14. Instalarea echipamentului



Acest echipament trebuie să fie instalat, înlocuit și/sau depanat numai de către personal instruit și calificat.

## 15. Eliminarea echipamentului



Eliminarea acestui echipament trebuie să se realizeze în conformitate cu toate legile și regulamentele naționale.

## 16. Codurile electrice locale și naționale



Acest echipament trebuie să fie instalat conform codurilor electrice locale și naționale.

## 17. Codurile de instalare



Acest dispozitiv trebuie să fie instalat în conformitate cu ultima versiune a codurilor electrice naționale ale țării în cauză. Pentru America de Nord, echipamentul trebuie să fie instalat conform cerințelor aplicabile din Codul electric național al SUA și Codul electric canadian.

## 18. Înlocuirea bateriei



Avertisment: Înlocuiți numai cu o baterie recunoscută UL, certificată pentru curent de încărcare anormal maxim de minimum 4 mA

Există risc de explozie în cazul în care bateria este înlocuită cu o baterie necorespunzătoare.

Eliminați bateriile folosite în conformitate cu instrucțiunile.

## 19. Cordon de alimentare electrică înregistrat UL și certificat CSA



Pentru conectarea la o sursă de alimentare pentru America de Nord, selectați un cordon de alimentare care este înregistrat UL și certificat CSA, cu 3 conductoare, [16 AWG], terminat cu o fișă turnată, cu putere nominală egală cu 125 V, [13 A], cu o lungime de minimum 1,5 m [șase picioare], dar nu mai lung de 4,5 m.

Pentru conectarea la o sursă de alimentare în Europa, selectați un cordon de alimentare care este armonizat la nivel internațional și marcat „<HAR>”, cu 3 conductoare, cu minimum 2 fire de 1,0 mm, cu putere nominală egală cu 300 V și cu o manta izolantă din PVC. Cordonul de alimentare trebuie să fie prevăzut cu o fișă turnată cu putere nominală egală cu 250 V, 10 A.

## 20. Curent de scurgere de înaltă frecvență



Avertisment: Curent de scurgere de înaltă frecvență; Împământarea este esențială înainte de a conecta sursa de alimentare.

## 21. Adăugarea de informații privind legarea la pământ



Înainte de a conecta acest dispozitiv la o linie electrică de energie, șuruburile bornelor de protecție de legare la pământ ale acestui dispozitiv trebuie să fie conectate la priza de pământ de protecție din instalația clădirii. (Informații privind legarea la pământ): Instalația clădirii va asigura un mijloc de conectare la priza de pământ, iar echipamentul va fi în mod permanent conectat la priza de pământ de un agent de întreținere.

UN AGENT DE ÎNTREȚINERE va verifica dacă priza - borna de ieșire prin intermediul căreia va fi alimentat echipamentul cu energie electrică asigură o conexiune la priza de pământ a clădirii. În caz contrar, AGENTUL DE ÎNTREȚINERE va dispune instalarea unui CONDUCTOR DE PROTECȚIE DE LEGARE LA PĂMÂNT de la borna separată de protecție de legare la pământ la cablul de protecție de legare la pământ al clădirii. Echipamentul va fi instalat într-o zonă unde există legături echipotențiale (precum un centru de telecomunicații sau o cameră a computerelor dedicată).

## 22. Codurile de instalare



Acest dispozitiv trebuie să fie instalat în conformitate cu ultima versiune a codurilor electrice naționale ale țării în cauză. Pentru America de Nord, echipamentul trebuie să fie instalat conform cerințelor aplicabile din Codul electric național al SUA și Codul electric canadian.

## 23. Interconectarea unităților



Cablurile pentru conectarea la unitatea RS232 și la interfețele Ethernet trebuie să fie de tipul DP-1 sau DP-2 certificate UL. (Notă- când se regăsesc într-un circuit non-LPS) Protecție la supracurent: Un dispozitiv de protecție la supracurent, înregistrat în circuitul de ramificare, ușor accesibil și cu o putere nominală egală cu 20 A trebuie să fie integrat în cablajul clădirii.

## 24. Expunerea la radiații periculoase



Atenție – Utilizarea elementelor de comandă sau ajustarea sau executarea altor proceduri decât a celor indicate în acest document poate avea ca rezultat expunerea la radiații periculoase.


PRODUS LASER CLASA 1 și referire la cele mai recente standarde pentru laser IEC 60 825-1:1993 + A1:1997 + A2:2001 și EN 60825-1:1994+A1:1996+ A2:2001

## 25. Carter adecvat




Un carter electric, mecanic și ignifug adecvat va fi furnizat de fabricantul produsului final și/sau utilizatorul final.

## 26. Nu utilizați comutatorul ca raft sau spațiu de lucru



Atenție: Echipamentul montat pe o linie de alunecare/șină nu va fi utilizat ca raft sau spațiu de lucru. Scopul șinelor nu este de a glisa unitatea de pe rack. Acestea sunt destinate instalării permanente numai la punctul final de oprire și nu vor fi folosite pentru depanare și întreținere

## 27. Directiva DEEE



În conformitate cu Directiva DEEE 2002/96/CE, toate deșeurile de echipamente electrice și electronice (EEE) trebuie colectate separat și nu trebuie eliminate împreună cu deșeurile menajere obișnuite.

Eliminați acest produs și toate componentele sale în mod responsabil și ecologic.

## G.8 Sigurnosna upozorenja za instaliranje (Croatian)

### 1. Upute za instaliranje




Pažljivo pročitajte upute za instaliranje prije spajanja opreme na izvor električne energije.

### 2. Tjelesne ozljede uslijed težine



Kako biste sigurno podignuli ovaj proizvod, koristite dovoljan broj ljudi.



### 3. Teška oprema



Ova oprema je vrlo teška i treba se premještati pomoću mehaničkog dizala kako bi se izbjegle ozljede.

### 4. Instaliranje na lokaciji s ograničenim pristupom



Ovaj uređaj je namijenjen za instaliranje na lokaciju s ograničenim pristupom.

### 5. Rizik od strujnog udara!



Rizik od strujnog udara!

S uklonjenim modulom ventilatora, perima napajanja se može pristupiti u otvoru modula.

NEMOJTE umetati alat ili dijelove tijela u otvor modula ventilatora.

### 6. Pregrijavanje



Ovom se opremom ne bi trebalo rukovati u područjima s temperaturom okoline koja premašuje najviše preporučene vrijednosti: 45°C (113°F). Osim toga, kako bi se osigurao odgovarajući protok zraka, omogućite najmanje 8 cm (3 inča) razmaka oko otvora ventilatora.

## 7. Slaganje kućišta



Kućište se ne bi trebalo slagati na drugu opremu. Ako kućište padne, može izazvati tjelesne ozljede i oštećenje opreme.

## 8. Redundantno napajanje - Opasnost od električne energije



Ovaj proizvod uključuje redundantno napajanje ili prazan prostor na njegovu mjestu. U slučaju praznog prostora za napajanje, nemojte rukovati proizvodom ako je poklopac uklonjen ili ako nije dobro pričvršćen.

## 9. Dvopolni/neutralni osigurači



Ovaj sustav raspolaže dvopolnim/neutralnim osiguračima. Uklonite sve kabele napajanja prije otvaranja poklopca proizvoda ili dodirivanja unutarnjih dijelova.

## 10. Višestruki ulazi za napajanje



Rizik od strujnog udara i opasnost od električne energije.

PSU jedinice su neovisne.

Odspojite sva napajanja kako biste osigurali stanje bez napajanja unutar platforme preklopnika.

## 11. Tijekom udara munje - Opasnost od električne energije



Tijekom djelovanja munja, nemojte raditi na opremi ili spajati ili odspajati kabele.

## 12. Spajanje/Odspajanje bakrenog kabla InfiniBand



Bakreni kabele InfiniBand su teški i nesavjetljivi i kao takvi se moraju pažljivo priključiti na ili isključiti iz konektora. Obratite se proizvođaču kabla za posebna upozorenja/upute.

## 13. Montaža ormarića i servisiranje



Kad se proizvod montira ili se servisira u ormariću, moraju se poduzeti posebne mjere opreza kako bi se osiguralo da sustav ostane stabilan. Općenito, trebali biste ispunjavati ormarić s opremom počevši od dna prema vrhu.

#### 14. Instaliranje opreme



Ovu bi opremu trebalo instalirati, zamjenjivati i/ili servisirati samo obučeno i kvalificirano osoblje.

#### 15. Odlaganje opreme



Odlaganje opreme trebalo bi se vršiti sukladno nacionalnim zakonima i propisima.

#### 16. Lokalni i nacionalni električni kodovi



Ova oprema trebala bi se instalirati u skladu s lokalnim i nacionalnim električnim kodovima.

#### 17. Instalacijski kodovi



Ovaj se uređaj mora instalirati sukladno najnovijoj verziji nacionalnih električnih kodova države. U Sjevernoj Americi oprema se mora instalirati sukladno važećim zahtjevima navedenim u US National Electrical Code i Canadian Electrical Code.

#### 18. Zamjena baterije



**Upozorenje:** Bateriju zamijenite samo baterijom iz serije UL koja je certificirana za maksimalnu nepravilnu struju punjenja ne manju od 4 mA. Postoji rizik od eksplozije ako se baterija zamijeni neodgovarajućom vrstom. Odložite prazne baterije sukladno uputama.

#### 19. UL CSA kabel napajanja



Za sjevernoameričku mrežu odaberite kabel napajanja koji je na UL listi i sa CSA certifikatom, 3 - žilni, [16 AWG] (16 AWG) koji završava lijevanim utikačem nazivnog napona od 125 V, [13 A], minimalne duljine od 1,5 m [six feet] (šest stopa), ali ne dulji od 4,5 m.

Za europsku mrežu odaberite kabel napajanja koji je međunarodno usklađen i označen "<HAR>", 3 - žilni, s najmanje 1,0 mm<sup>2</sup> žice, nazivnog napona od 300 V, s PVC izolacijom. Kabel mora imati lijevani utikač nazivnog napona od 250 V, nazivne struje od 10 A.

#### 20. Veliko curenje struje



**Upozorenje:** Veliko curenje struje; Prije spajanja napajanja nužno je spojiti uzemljenje.

## 21. Dodaj informaciju o GND spoju



Prije spajanja ovog uređaja na električni vod, vijci terminala zaštitnog uzemljenja uređaja moraju se spojiti na zaštitno uzemljenje u instalacijama zgrade. (Informacija o GND spajanju):

Instalacije u zgradi omogućit će sredstva za spajanje na zaštitno uzemljenje; a servisno osoblje će trajno održavati spoj opreme s uzemljenjem.

SERVISNO OSOBLJE će provjeriti omogućuje li ili ne zidna utičnica napajanja za opremu spoj na zaštitno uzemljenje zgrade. Ako ne, SERVISNO OSOBLJE će organizirati instaliranje VODIČA ZAŠTITNOG UZEMLJENJA iz posebnog terminala zaštitnog uzemljenja na žicu zaštitnog uzemljenja u zgradi. Oprema će se instalirati u područje gdje postoje ekvipotencijalni spojevi (poput telekomunikacijskog centra ili namjenske računalne sobe).

## 22. Instalacijski kodovi



Ovaj se uređaj mora instalirati sukladno najnovijoj verziji nacionalnih električnih kodova države. U Sjevernoj Americi oprema se mora instalirati sukladno važećim zahtjevima navedenim u US National Electrical Code i Canadian Electrical Code.

## 23. Interkonekcija uređaja



Kabeli za spajanje na jedinicu RS232 i Ethernet sučelja moraju biti s UL certifikatom vrste DP-1 ili DP-2. (Napomena - kad se nalazi u krugu bez LPS vodiča)

Zaštita od strujnog preopterećenja: Uvijek dostupni odobreni zaštitni uređaji od strujnog preopterećenja nazivne struje od 20 A moraju se ugraditi u ožičenje zgrade.

## 24. Izloženost opasnom zračenju



Pozor – Korištenje kontrola, prilagodba ili izvođenje postupaka koji se razlikuju od onih koji su ovdje navedeni može izazvati izlaganje opasnom zračenju.




LASERSKI PROIZVOD KLASA 1 i referenca na najnovije laserske standarde IEC 60 825-1:1993 + A1:1997 + A2:2001 i EN 60825-1:1994+A1:1996+A2:2001

## 25. Odgovarajuća okolina




Odgovarajuće električno, mehaničko i protupožarno okruženje trebao bi omogućiti proizvođač krajnjeg proizvoda i ili krajnji korisnik.

## 26. Nemojte koristiti preklopnik kao policu ili radnu površinu



Pozor: Oprema montirana na klizače/vodilice ne bi se trebala koristiti kao policu ili radna površina. Vodilice nisu namijenjene za povlačenje uređaja iz ormarića. Služe samo za trajnu instalaciju na konačnom položaju, a ne za servisiranje i održavanje.

## 27. WEEE direktiva



Sukladno WEEE direktivi 2002/96/EZ, sav električni i elektronički otpad (EEE) trebao bi se prikupljati zasebno i ne bi se trebao odlagati kao običan kućanski otpad. Odlaganje ovog proizvoda i svih njegovih dijelova vršite na odgovoran i ekološki način.

## 28. Električna ograničenja države Norveške



Ovaj je uređaj namijenjen samo za spajanje na električni sustav s TN uzemljenjem i na električni sustav s IT uzemljenjem države Norveške.